

AD-A054 802 ARMY ENVIRONMENTAL HYGIENE AGENCY ABERDEEN PROVING GR--ETC F/G 6/18  
HAZARD ANALYSIS OF BROAD-BAND OPTICAL SOURCES.(U)  
DEC 77 D H SLINNEY, W J MARSHALL


ARMY ENVIRONMENTAL HYGIENE AGENCY ABERDEEN PROVING GR--ETC F/G 6/18  
HAZARD ANALYSIS OF BROAD-BAND OPTICAL SOURCES.(U)  
DEC 77 D H SLINEY, W J MARSHALL

USAEHA-TG-084

NL

1 OF 1  
AD  
A054802

END  
DATE  
FILMED  
7-78  
DDC



MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A

FOR FURTHER TRAN

Approved for public release; distribution unlimited.


AD A 054802

TG 084

12

HAZARD ANALYSIS OF BROAD-BAND OPTICAL SOURCES  
DECEMBER 1977

THIS DOCUMENT IS BEST QUALITY PRACTICABLE.  
THE COPY FURNISHED TO DDC CONTAINED A  
SIGNIFICANT NUMBER OF PAGES WHICH DO NOT  
REPRODUCE LEGIBLY.



AD No. \_\_\_\_\_  
DDC FILE COPY

DDC  
RECEIVED  
JUN 9 1978  
E

US ARMY  
ENVIRONMENTAL HYGIENE AGENCY  
ABERDEEN PROVING GROUND, MD 21010

## **DISCLAIMER NOTICE**

**THIS DOCUMENT IS BEST QUALITY  
PRACTICABLE. THE COPY FURNISHED  
TO DDC CONTAINED A SIGNIFICANT  
NUMBER OF PAGES WHICH DO NOT  
REPRODUCE LEGIBLY.**



UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER	2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) <b>HAZARD ANALYSIS OF BROAD-BAND OPTICAL SOURCES</b> <b>DECEMBER 1977</b>		5. TYPE OF REPORT & PERIOD COVERED <b>December 1977</b>
6. AUTHOR(s) <b>David H. Sliney, Wesley J. Marshall, Michael L. Carothers, Richard C. Kaste</b>		7. PERFORMING ORG. REPORT NUMBER
8. PERFORMING ORGANIZATION NAME AND ADDRESS <b>US Army Environmental Hygiene Agency Aberdeen Proving Ground, MD 21010</b>		9. CONTRACT OR GRANT NUMBER(s) <b>USA EHA-TG-084</b>
10. CONTROLLING OFFICE NAME AND ADDRESS <b>Commander US Army Health Services Command Fort Sam Houston, TX 78234</b>		11. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS
12. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office) <b>Technical guide,</b>		13. REPORT DATE
		14. NUMBER OF PAGES <b>86</b>
		15. SECURITY CLASS. (of this report) <b>UNCLASSIFIED</b>
16. DISTRIBUTION STATEMENT (of this Report) <b>Approved for public release; distribution unlimited.</b>		17. DECLASSIFICATION/DOWNGRADING SCHEDULE
18. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
19. SUPPLEMENTARY NOTES		
20. KEY WORDS (Continue on reverse side if necessary and identify by block number) Light Hazardous Exposure Infrared Radiation Safety Ultraviolet Radiation Mercury Arc Optical Radiation Source		
21. ABSTRACT (Continue on reverse side if necessary and identify by block number) This technical guide provides an explanation of the techniques used by the Laser Branch, Laser Microwave Division, US Army Environmental Hygiene Agency, to evaluate non-laser optical sources. Hazard criteria and spectral data reduction techniques are explained. Radiometric measurements are not included. The Laser Microwave Division Spectral Weighting Program (LMDSWP--a Fortran V computer program) is presented in detail.		

DD FORM 1 JAN 73 1473

EDITION OF 1 NOV 65 IS OBSOLETE

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

# Technical Guide - Hazard Analysis of Broad-Band Optical Sources

## CONTENTS

Paragraph	Page
1. BACKGROUND -----	1
2. REQUIRED RADIOMETRIC DATA -----	1
3. MEASUREMENT TECHNIQUES -----	2
4. SPECTRAL HISTOGRAM -----	2
5. PROCESSING OF DATA -----	2
6. ABSOLUTE VERSUS RELATIVE SPECTRAL IRRADIANCE MEASUREMENTS -----	4
7. SPECTRAL RADIANCE MEASUREMENTS -----	4
8. BIOLOGICAL WEIGHTING FUNCTIONS -----	4
a. Ultraviolet Radiation (200-400 nm) -----	4
b. Visible Radiation (400-770 nm) and Near-Infrared Radiation (770-1400 nm) -----	5
c. Infrared Exposure (770 nm to 1 mm) -----	10
9. AMBIENT LIGHT LEVELS -----	10
10. REFERENCES -----	13
APPENDIX	
A - Program Description -----	A-1
B - Computer Listing -----	B-1
C - Operating Instructions -----	C-1
D - Useful CIE Radiometric and Photometric Terms and Units -----	D-1

ACCESSION for	
NTIS	White Section <input checked="" type="checkbox"/>
DOC	Buff Section <input type="checkbox"/>
UNANNOUNCED	<input type="checkbox"/>
JUSTIFICATION.....	
BY.....	
DISTRIBUTION/AVAILABILITY CODES	
Dist.	AVAIL. and/or SPECIAL
A	23 84



**DEPARTMENT OF THE ARMY**  
**U. S. ARMY ENVIRONMENTAL HYGIENE AGENCY**  
**ABERDEEN PROVING GROUND, MARYLAND 21010**

**HSE-RL Technical Guide**

**1 April 1978**

**HAZARD ANALYSIS OF BROAD-BAND OPTICAL SOURCES**  
**DECEMBER 1977**

This technical guide provides an explanation of the techniques used by the Laser Branch, Laser Microwave Division, US Army Environmental Hygiene Agency, to evaluate non-laser optical sources. Hazard criteria and spectral data reduction techniques are explained. Radiometric measurements are not included. The Laser Microwave Division Spectral Weighting Program (LMDSWP--a Fortran V computer program) is presented in detail.





DEPARTMENT OF THE ARMY  
U. S. ARMY ENVIRONMENTAL HYGIENE AGENCY  
ABERDEEN PROVING GROUND, MARYLAND 21010

HSE-RL/WP Technical Guide

1 April 1978

HAZARD ANALYSIS OF BROAD-BAND OPTICAL SOURCES

1. BACKGROUND.

a. The Laser Branch, Laser Microwave Division, US Army Environmental Hygiene Agency (USAEHA), evaluates hazards from not only lasers, but also broad-band optical sources. Examples of such sources include searchlights, infrared missile guidance systems, optical beacons and hospital ultraviolet lamps. This guide explains the techniques used to reduce spectroradiometric measurements of such sources. To evaluate a broad-band optical source such as an arc, a lamp or an array of lamps as are found in hospital, military and industrial equipment, it is necessary to determine the spectral distribution of the optical radiation. The spectral distribution of interest is that of the accessible emission, which may differ from that of the open arc or lamp due to filtration by a plastic or glass window or by other optical elements in the system. The final hazard analysis of an optical source requires the weighted sum of several spectroradiometric parameters to estimate total retinal irradiance and biologically-weighted corneal and skin irradiance. How these weighted sums are evaluated is explained in detail in "The Evaluation of Optical Radiation Hazards" by D. H. Sliney and B. C. Freasier, Applied Optics, Volume 12, pages 1-24, January 1973 (reference 10d). Ultraviolet radiation exposure limits are provided in AR 40-46.

b. During 1976-1977, a new computer program -- The Laser Microwave Division Spectral Weighting Program (LMDSWP) -- was developed by the Data Processing and Technical Information Services Branch of USAEHA and is explained in this guide in Appendix A. Appendix B provides a program listing and a table of values for the spectral weighting functions. Appendix C provides operating instructions for using the program.

2. REQUIRED RADIOMETRIC DATA. The spectral irradiance  $E_\lambda$  should be complete from 200 nm to at least 1400 nm. For fluorescent lamps and many arc lamps, little infrared radiation beyond 1200 nm exists and can be neglected if instrument capability is limited to 1200 nm. The spectral irradiance  $E_\lambda$  at the nearest point of access (usually at the glass cover) is of interest in assessing potential ultraviolet hazards to the skin and eye, and potential hazards to the skin from the entire spectrum. The spectral radiance  $L_\lambda$  is of interest for assessing potential hazards to the retina and should be complete from 400 to 1400 nm (the retinal hazard region). Again, the actual measurements beyond 1200 nm can generally be neglected. The values of  $L_\lambda$  may be closely estimated from  $E_\lambda$  values and source dimensions. Radiometric quantities are defined in Appendix D.

## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

3. MEASUREMENT TECHNIQUES. The spectrum of an open arc process (e.g., welding arc), an arc lamp, a gas discharge lamp or a fluorescent lamp consists of line structure plus a continuum. Significant errors can be made in representing the spectrum and weighting the spectrum against a biological action spectrum if the fraction of energy in each line is not properly added to the continuum. The first panel of Figure 1 shows a hypothetical spectral recording from a spectroradiometer. If spectral points were arbitrarily recorded every 5 nm, most of the line-peak recordings would be missed. The width of the triangular line at half of the peak is called the band-width of the monochromator/spectroradiometer. The recommended method for representing the spectrum in tabular form is to provide the measured spectral irradiance [ $\mu\text{W}/(\text{cm}^2 \cdot \text{nm})$ ] of the continuum at regular intervals (typically every 5 nm) and then list separately the irradiance ( $\mu\text{W}/\text{cm}^2$ ) in each line. The latter values are determined by subtracting the continuum spectral irradiance at the spectral line from the peak reading and multiplying that value by the bandwidth of the monochromator (typically 2 to 5 nm). These line irradiances are listed separately.

4. SPECTRAL HISTOGRAM. For graphical illustrations, the continuum and line structure is recombined by the computer program into a histogram. The spectral divisions of the histogram most accurately present the spectral resolution of the data. If the spectrum is represented in 5-nm intervals, the irradiance of each line is divided by 5 nm and added to the continuum spectral irradiance value in that 5-nm interval in which the emission line is located. As an example, we may wish to represent the spectrum of a mercury arc by having points at 300 nm, 305 nm, 310 nm, 315 nm, etc. The 5-nm band centered at 305 nm (i.e., 302.5 to 307.5 nm) contains the 303-nm emission line of mercury; likewise, the band centered at 315 nm contains the 313-nm emission line. Since the band centered at 310 nm contains no emission line of mercury, it truly represents only the continuum. Panel 3 of Figure 1 illustrates a histogram plot.

5. PROCESSING OF DATA. Many of the calculations which are useful in hazard analysis require weighting the spectrum against a biological action spectrum (e.g., erythema or photokeratitis action spectrum, the photopic response of the eye, and the retinal-injury action spectrum). The LMDSWP computer program (Appendix B) was developed to simplify this data reduction. Normally, there is little error introduced by using the digitized spectral irradiance values used in the histogram plot for this process. However, if the lamp spectrum is changing rapidly at the same location where the weighting spectrum undergoes a rapid change, significant errors can be introduced. It is, therefore, preferable to weight the line values separately when one type of lamp is routinely evaluated. The mercury lines (254, 293, 303, 313, 365, 405, 435 nm, etc.) are found not only in mercury lamps but also in fluorescent lamps. Routine hand-computing techniques and the machine-computing routine separately weight two spectra and then add them afterward.

# Technical Guide - Hazard Analysis of Broad-Band Optical Sources




Figure 1. Hypothetical Spectral Data Reduction. The instrument reading is divided by the calibration factor to yield the spectral irradiance.



## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

6. ABSOLUTE VERSUS RELATIVE SPECTRAL IRRADIANCE MEASUREMENTS. Absolute spectral irradiance or spectral radiance measurements are not always essential. Photometric-to-radiometric conversion factors (lumen/watt ratios) can be obtained from a relative spectrum of the lamp taken at any accessible location. Provided that a luminance and illuminance measurement are made at a point of interest, the absolute spectroradiometric values can be calculated. This latter approach is often preferable since illuminance ( $\text{lm}/\text{cm}^2$ ) and luminance ( $\text{cd}/\text{cm}^2$ ) measurements can be made rapidly at many accessible points of interest. Provided that the spectrum does not change from one point to another, the ultraviolet-radiation hazard and retinal-injury hazard can be calculated at all such points. Because of the limits of sensitivity introduced by photocathode noise in typical spectroradiometers, it is often not possible to obtain spectral irradiance values at some distance from the source. This problem is particularly acute in the near infrared beyond 1000 nm. By measuring the relative spectral irradiance as near to the source as possible, this problem can be greatly reduced. The LMDSWP computer program calculates a lumen-to-watt conversion factor.

7. SPECTRAL RADIANCE MEASUREMENTS. The spectral radiance  $L_\lambda$  [ $\mu\text{W}/(\text{cm}^2 \cdot \text{nm})$ ] is the spectral irradiance  $E_\lambda$  at a point of measurement divided by the solid angle of the source. It is typical to measure  $E_\lambda$  from one bright spot on the source. This can be accomplished by using an irradiance meter with a very small field-of-view or by occluding all but a small portion of the source with a mask. The solid angle of the source then becomes the exposed area of the source  $A_s$  divided by the square of the distance  $r$  from this area to the instrument:

$$L = E/\Omega_s \quad \text{and} \quad \Omega_s = A_s/r^2 \quad (1)$$

8. BIOLOGICAL WEIGHTING FUNCTIONS. Several potential hazards must be evaluated separately for different spectral bands and biological weighting functions must be employed for this purpose.

a. Ultraviolet Radiation (200-400 nm). The potential hazards associated with ultraviolet radiation exposure of the eye and skin must be considered in each of two spectral regions. These regions are the actinic (or UV-B and UV-C) region, where photokeratitis, conjunctivitis (as with "welder's flash") and erythema (as with "sunburn") are the health hazards associated with this form of radiation exposure; and the near ultraviolet (UV-A) spectral region, where the effects are not well known, but cataractogenesis has been suggested. Cataractogenesis may also result from UV-B.

(1) Actinic UV. Standards for exposure to the eye and skin developed at USAEHA and now recommended by both the American Conference of Governmental Industrial Hygienists (ACGIH) and the National Institute of Occupational Safety and Health (NIOSH) of the US Department of Health, Education, and Welfare have generally become accepted in the USA -- particularly where

## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

ocular exposure is of concern (references 10a - 10c). The limit for exposure is based upon an "envelope" action spectrum for photokeratitis and erythema. The spectrum from the source at the nearest accessible point is weighted by this curve (Figure 2 and Table 1) for wavelengths less than 318 nm.

The weighting formula is:  $E_{eff} = \sum E_{\lambda} \cdot S_{\lambda} \cdot \Delta\lambda$  (2)

and the permissible 8-hour limit for exposure is  $10^{-7}$  W/cm<sup>2</sup> for  $E_{eff}$  (a total corresponding to an exposure dose of 3 mJ/cm<sup>2</sup>).

(2) Near-Ultraviolet Radiation. Criteria for limiting personnel exposure to UV-A radiation (320-400 nm) are presently based upon limited biological data. The solar irradiance incident upon the skin of an individual out-of-doors is normally 1-4 mW/cm<sup>2</sup>. The level of 1 mW/cm<sup>2</sup> is often used as a safe exposure limit (references 10a - 10d). Summing the spectral irradiance,  $E_{\lambda}$ , from 320 to 400 nm, one obtains the total irradiance in the UV-A.

### b. Visible Radiation (400-770 nm) and Near-Infrared Radiation (770-1400 nm).

(1) Blue Light Hazard. The exact boundaries for light (or "visible radiation") are often argued; at present, the International Commission on Illumination (CIE) sets 380-400 nm to 760-780 nm as "visible." However, of principal interest in most USAEHA special studies, is the effect of all radiations from 400 to 1400 nm that reach the retina. Except for small children and aphakics (those with the crystalline lens removed by cataract surgery), so little UV-A radiation reaches the retina that retinal exposure in that spectral region is considered insignificant. Until recently, retinal injury from high-intensity light sources was thought to be thermal injury to retinal tissue. In the past few years, it has become increasingly evident that a photic effect which has as its basis a photochemical (e.g., phototoxic) reaction is responsible for threshold light-induced retinal injury for exposure durations exceeding 10 seconds (references 10d - 10g). The blue-light wavelengths near 440 nm appear to be by far the most hazardous. Although laser safety standards reflect a photochemical injury hypothesis for light exposures greater than 10 seconds, they were initially based on very little data available at the time of their development -- 1973 (references 10d and 10h). For the purpose of evaluating noncoherent, broad-band sources, it is more reasonable to develop a standard for lamp exposures directly from the threshold retinal injury data. A blue-light hazard function,  $B_{\lambda}$ , was developed at USAEHA from the data of Ham and is given in Table 2. It has since been proposed as a possible future TLV® by ACGIH.

---

® TLV - Threshold Limit Values for Chemical Substances and Physical Agents in the Workroom Environment with Intended Changes for 1977.

Technical Guide - Hazard Analysis of Broad-Band Optical Sources




Figure 2. Recommended Ultraviolet Radiation Exposure Standard. This figure was adapted from a figure developed and published by the American Conference of Governmental Industrial Hygienists in "Threshold Limit Values for Chemical Substances and Physical Agents in the Workroom Environment with Intended Changes for 1977".



# Technical Guide - Hazard Analysis of Broad-Band Optical Sources

TABLE 1. RELATIVE SPECTRAL EFFECTIVENESS BY WAVELENGTH

Wavelength (nm)	TLV (mJ/cm <sup>2</sup> )*	Relative Spectral Effectiveness S <sub>λ</sub>
200	100	0.03
210	40	0.075
220	25	0.12
230	16	0.19
240	10	0.30
250	7.0	0.43
254	6.0	0.5
260	4.6	0.65
270	3.0	1.0
280	3.4	0.88
290	4.7	0.64
300	10	0.30
305	50	0.06
310	200	0.015
315	1000	0.003

\* 1 mJ/cm<sup>2</sup> = 10<sup>-3</sup> J/cm<sup>2</sup>

# Technical Guide - Hazard Analysis of Broad-Band Optical Sources

TABLE 2. SPECTRAL WEIGHING FUNCTIONS FOR ASSESSING RETINAL HAZARDS FROM BROAD-BAND OPTICAL SOURCES

Wavelength (nm)	Blue-Light Hazard Function $B_{\lambda}$	Burn Hazard Function $R_{\lambda}$
400	0.10	1.0
405	0.20	2.0
410	0.40	4.0
415	0.80	8.0
420	0.90	9.0
425	0.95	9.5
430	0.98	9.8
435	1.0	10.0
440	1.0	10.0
445	0.97	9.7
450	0.94	9.4
455	0.90	9.0
460	0.80	8.0
465	0.70	7.0
470	0.62	6.2
475	0.55	5.5
480	0.45	4.5
485	0.40	4.0
490	0.22	2.2
495	0.16	1.6
500-600	$10^{[(450-\lambda)/50]}$	1.0
600-700	0.001	1.0
700-1060	0.001	$10^{[(\lambda-700)/515]}$
1060-1400	0.001	0.2

## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

(2) Retinal Exposure. To consider a retinal injury safety standard, we must first define the relation between retinal levels and lamp brightness (or radiance). The retinal irradiance  $E_r$  is related to the source radiance  $L_s$  that is being directly viewed and is independent of viewing distance. It is also influenced by the transmission  $\tau$  of the ocular media in front of the retina and upon the pupil diameter  $d_e$ , which for a bright visible source is normally less than 3 mm. The relation is:

$$E_r = 0.27 L_s \cdot \tau \cdot d_e^2 \quad (3)$$

This equation may be used to calculate the retinal irradiance at just one wavelength or in a narrow wavelength band (e.g., blue light), or it may be used to calculate the total retinal irradiance from 400 to 1400 nm. In the latter case, the spectral radiance distribution  $L_\lambda$  must be weighted against the spectral transmittance of the ocular media  $\tau_\lambda$  to obtain an average or effective transmittance of the ocular media,  $\tau_{eff}$  (reference 10h). The formula is:

$$\tau_{eff} = \frac{\sum L_\lambda \cdot \tau_\lambda \cdot \Delta\lambda}{\sum L_\lambda \cdot \Delta\lambda} \quad (4)$$

(3) Photometric Values. The source brightness can also be considered in photometric terms.

The luminance  $L_v$  of the source is found by:

$$L_v = 683 \sum V_\lambda \cdot L_\lambda \cdot \Delta\lambda \quad (5)$$

Using this formula and the CIE luminous efficiency function  $V_\lambda$  which has a maximal value of 1.0 at 550 nm where the radiometric-to-photometric conversion factor is 683 lumens/watts, from formula (5) the luminance is calculated. Following the same approach for total illuminance  $E_v$  at the point where  $E_\lambda$  was measured is:

$$E_v = 683 \sum V_\lambda \cdot E_\lambda \cdot \Delta\lambda \quad (6)$$

These formulae also permit one to calculate the luminous efficacy of radiation from the lamps in lumens/watt. If the spectrum is weighted against the scotopic (rod) response functions  $V_\lambda^s$ , we then obtain the scotopic efficiency, where the maximal value would be 1.0 at 500 nm (the peak response of rods). Although photometric quantities are not normally used solely for comprehensive hazard evaluation, many relatively inexpensive measuring instruments may be used as a crosscheck on radiometrically measured values. Furthermore, cosine-corrected photometric instruments may be used to cosine-correct spectrally measured UV data.

(4) Exposure Limits. Simplified standard limits developed at USAEHA and also proposed as a future TLV by ACGIH for broad-band light sources provide the following limits expressed in terms of the source radiance.



## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

(a) To protect against retinal thermal injury, the spectral radiance of the lamp weighted against the function  $R_\lambda$  (Table 2) should not exceed:

$$L(\text{HAZ}) = \sqrt{t}/\alpha \quad (7)$$

where  $L$  is in  $\text{W}/(\text{cm}^2 \cdot \text{sr})$  and  $t$  is the viewing duration (or pulse duration if the source is pulsed) limited to  $1 \mu\text{s}$  to 10 seconds, and  $\alpha$  is the angular subtense of the source in radians. If the source is oblong (e.g., a tubular flash lamp), the angle refers to the longest dimension. For instance, at a viewing distance  $r = 100 \text{ cm}$  from a xenon flash lamp of length  $\ell = 50 \text{ cm}$  the approximate viewing angle is:

$$\alpha = 2[\arctan(\ell/2r)]$$

or:

$$\begin{aligned} \alpha &\approx \ell/r \quad \text{for small } \alpha \\ &\approx 50/100 = 0.5 \text{ radian} \end{aligned} \quad (8)$$

This relationship may also be expressed in retinal terms; i.e., irradiance and image diameter. The USAEHA retinal hazard function is graphed in Figure 3.

(b) To protect against retinal injury from blue-light exposure, the integrated spectral radiance of the lamp weighted against the blue-light hazard function  $B_\lambda$  (Table 2) should not exceed:

$$\begin{aligned} L_p(\text{HAZ}) &= 100 \text{ J}/(\text{cm}^2 \cdot \text{sr}) \text{ for } t < 10^4 \text{ seconds} \\ L(\text{HAZ}) &= 10 \text{ mW}/(\text{cm}^2 \cdot \text{sr}) \text{ for } t > 10^4 \text{ seconds} \end{aligned} \quad (9)$$

For a source radiance  $L$  which exceeds  $2 \text{ mW}/(\text{cm}^2 \cdot \text{sr})$  in the blue region, the permissible exposure duration  $t$  (max) in seconds is simply:

$$t(\text{max}) = 100 \text{ J}/(\text{cm}^2 \cdot \text{sr}) / L(\text{blue}) \quad (10)$$

These latter limits are greater than maximum permissible exposure limits for 440-nm laser radiation (AR 40-46 and ANSI Z-136.1).

c. Infrared Exposure (770 nm to 1 mm). The total accessible average irradiance in the infrared from most sources should be kept below  $10 \text{ mW}/\text{cm}^2$ . This value is to protect against either retinal injury or cataractogenesis (reference 10d). The IR-A radiance should be less than  $0.6/\alpha$ .

9. **AMBIENT LIGHT LEVELS.** It is often considered useful to compare the spectral radiance of a lamp to the same spectral radiance of natural light sources. Figure 4 is a plot of spectral radiance of the solar disc ( $\Omega_s = 6.9$




Figure 3. USAEHA Permissible Retinal Irradiance for Momentary Viewing of Extended Sources as a Function of Retinal Image Size.

# Technical Guide - Hazard Analysis of Broad-Band Optical Sources




Figure 4. Spectral Radiance of the Summer Sun for Two Localities. Note the change in short-wavelength spectral irradiance as the sun approaches sunset.

## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

$\times 10^{-5} \cdot \text{sr}$ ) and of an average blue-sky condition. To calculate the spectral radiance of snow at noonday, divide the uppermost curves by 50,000. For example, the approximate noonday spectral radiances at 440 nm are (from Figure 4):

Sun:  $1.3 \text{ W}/(\text{cm}^2 \cdot \text{sr} \cdot \text{nm})$

Snow:  $2.6 \times 10^{-5} \text{ W}/(\text{cm} \cdot \text{sr} \cdot \text{nm})$

Sky:  $7 \times 10^{-6} \text{ W}/(\text{cm}^2 \cdot \text{sr} \cdot \text{nm})$

Until a thorough understanding of chronic exposure hazards to the eye has developed, one should be concerned about ocular exposures to the levels exceeding those of the latter two sources for long periods of time (reference 10i).

### 10. REFERENCES.

- a. American Conference of Governmental Industrial Hygienists, "Threshold Limit Values for Chemical Substances and Physical Agents in the Workroom Environment with Intended Changes for 1977," ACGIH, Cincinnati, OH (1977)
- b. National Institute of Occupational Safety and Health, "Criteria for a Recommended Standard, Occupational Exposure to Ultraviolet Radiation," US Department of Health, Education, and Welfare, Washington, DC (1972)
- c. Sliney, D. H., "The Merits of an Envelope Action Spectrum for Ultraviolet Exposure Criteria," Amer. Indust. Hyg. Assn. J, 33(10):644-653 (October 1972)
- d. Sliney, D. H. and Freasier, B. C., "The Evaluation of Optical Radiation Hazards," Appl. Opt., 12(1):1-24 (January 1973)
- e. Harwerth, R. S. and Sperling, H. G., "Prolonged Color Blindness Induced by Spectral Lights in Rhesus Monkeys," Science, 174(4008):520-522 (29 October 1971)
- f. Lawwill, T., "Effects of Prolonged Exposure of Rabbit Retina to Low-Intensity Light," Invest. Ophthalm., 12:45-51 (1973)
- g. Ham, W. T., JR., H. A. Mueller and D. H. Sliney, "Retinal Sensitivity to Damage from Short Wavelength Light," Nature, 260:153-155 (1976)
- h. American National Standards Institute, "Safe Use of Lasers," Z-136.1, ANSI, New York, NY (1976)
- i. Sliney, D. H., "The Ambient Light Environment and Ocular Hazards," Retinitis Pigmentosa (eds. M. B. Landers, et al.), pp 211-221, Plenum, New York (1977)



Technical Guide - Hazard Analysis of Broad-Band Optical Sources

APPENDIX A  
PROGRAM DESCRIPTION

PROGRAM: Laser Microwave Division Spectral Weighting Program (LMDSWP)

LANGUAGE: FORTRAN (EXEC 8 run stream)

PURPOSE: Calculate spectral irradiance data from uncorrected instrument readings, weight by biological and filter transmittance functions, and produce tables and graphs.

INPUT: Description and control cards  
Weighting functions data  
General function data  
Source spectral data

OUTPUT: Print-out of certain input values  
Print-out of calculated data  
Calcomp plots of certain calculated data

SEQUENCE: Each set of data cards must be ordered in ascending wave length (card columns 1-4)

INPUT DATA: For a column-by-column description of the input data cards see coding forms and card layout sheets. Of critical importance to LMDSWP is proper ordering of data values according to associated wavelength. The FORTRAN name and printer heading for wave length is LAMBDA. Comments follow concerning input data.

a. Biodeck. The unitless functions of wave length set forth in Table 1 are seldom changed and are used routinely.

b. Calibration Data: For each of seven instruments there are two 'spectral calibration functions', one associated with a visible light calibration source and one with an ultraviolet source. A spectral calibration value at a given wavelength is computed by dividing the instrument reading by the source irradiance.

## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

### PROGRAM DESCRIPTION

1. Read two 'project description' cards for use in the printer output heading. The cards should contain the project number, date of initiation, and a brief description.
2. Read the 'calculation control' card, which contains the number of filters considered (FORTRAN name NUMFIL may take on values 0,1, or 2), the form of the filter transmission functions in terms of the number of data fields to be read per filter (FORTRAN NOCOFT = 1 for precalculated, 2 for raw data pairs), the form of the calibration data to be read (integer CALDAT = 0 for raw data pairs, 1 for precalculated, 2 for program to generate '1.0' for all wavelengths), the weighting calculation to be performed (integer GENWEI = 00-15; see Table 2), whether a general function is to be read (integer GENFUN = 1) or the program-initialized function of 'one' for all wavelengths is to be used (GENFUN = 0).
3. Read the fourth 'distance factor' card for adjustment of source data by the inverse - square law. There is a factor (FORTRAN DFU) for UV wavelengths and another (DFV) for visible wavelengths.

The first four control cards must be present in each run. The data yet to be described are optional, and depend on 'calculation control' parameters.
4. Read (unless CALDAT = 2) and process calibration data.
  - a. If data are precalculated, multiply by DFU for wavelengths less than or equal to 300 nm or by DFV for wavelengths greater than 300.
  - b. If data are in raw form, read dividends, then divisors; check for wavelength matches; perform divisions; and incorporate distance factors as in (a).
5. Read biological data deck (BIODEK): S-, U-, V-, V\*-, T-, T-A-, C-A-, and A-LAMBDA are separated into wavelength-paired arrays.
6. Read, also into paired arrays, remaining biological data, one set at a time: B-LAMBDA, X-BAR LAMBDA, Y-BAR LAMBDA, Z-BAR LAMBDA, P-445, P-535, and P-575.
7. Read filter transmission data, if any, and process if necessary.
  - a. If data are in precomputed form, read wavelength and transmission values.
  - b. If data are in raw form, read wavelength, dividend, and divisor. Perform division and store result as in (a). For a two-filter case, filter two is considered first.



## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

8. The general function array FOFX was initialized to all 'ones' at the program beginning. If calculation control GENFUN=1, read general function data into FOFX.
9. Read data for the source under study: name of event, solid angle, and spectral data. Disregard data with wavelength less than the largest previously read wavelength. Negate wavelengths of cards punched with 'PEAK'; this distinction is necessary for the following calculation.
10. Determine the DELTA value associated with each wavelength, for use in various spectral weightings.
11. A wavelength interval for source readings (or intermediately-calculated values) may not exactly match an interval for biological or calibration data. Therefore, in weighting calculations subroutine INTERP may be called to use source deck wavelengths for interpolation of 'bio' or 'cal' values.
12. Perform calculations to obtain:  $E_{\text{fofx}}(\lambda)$ ;  $E_{\lambda}; L_{\lambda}; E_{\lambda} \cdot F_{\lambda}(1), E_{\lambda} \cdot F_{\lambda}(2)$ , or  $E_{\lambda} \cdot F_{\lambda}(1,2)$ ;  $E_r(\lambda)$ ; G-LAMBDA; integrated sums of source irradiance multiplied spectrally by filter and bio functions; and percentages of total irradiance which are UV, visible, or near-IR radiation.
13. Create Calcomp plot file containing header record, wavelengths, and data.
14. Print the calculated data.
15. Read and process the next set, if any, of spectral data.
16. After all spectral sets have been processed, create a Calcomp plot tape for histogram presentation of output.

# Technical Guide - Hazard Analysis of Broad-Band Optical Sources

<u>FUNCTION</u>	<u>FORTTRAN NAME</u>	<u>PRINTER HEADING</u>	<u>DESCRIPTION</u>
$S_{\lambda}$	SLAMBD	S-LAMBDA	ACGIH UV hazard envelope function
$U_{\lambda}$	ULAMBD	U-LAMBDA	1936 CIE UV skin erythema action spectrum
$A_{\lambda}$	ALAMBD	A-LAMBDA	ANSI Z136 laser weighting - UV hazard function
$T_{\lambda}$	TLAMBD	T-LAMBDA	Ocular media transmission
$T_{\lambda} \cdot A_{PE\lambda}$	TALAMB	T-A-LAMBDA	Absorption in the retina
$i/C_{\lambda}$	CALAMB	C-A-LAMBDA	Reciprocal of ANSI near-IR retinal burn correction factor
$V_{\lambda}$	VLAMBD	V-LAMBDA	CIE-1970 photopic visibility function
$V'_{\lambda}$	VPLAMB	V*-LAMBDA	CIE-1970 scotopic visibility function
$B_{\lambda}$	BLAMBD	B-LAMBDA	ACGIH blue-light hazard function
$\bar{X}_{\lambda}$	XBLAMB	X-BAR LAMBDA	CIE-1931 blue chromaticity coordinate
$\bar{Y}_{\lambda}$	YBLAMB	Y-BAR LAMBDA	CIE-1931 green chromaticity coordinate
$\bar{Z}_{\lambda}$	ZBLAMB	Z-BAR LAMBDA	CIE-1931 red chromaticity coordinate
$P_{445}$	P445LB	P-445	Dartnall nomogram absorption coefficient for blue
$P_{535}$	P535LB	P-535	Dartnall nomogram absorption coefficient for green
$P_{575}$	P575LB	P-575	Dartnall nomogram absorption coefficient for red

TABLE 1. Biodeck Data

# Technical Guide - Hazard Analysis of Broad-Band Optical Sources

<u>CODE</u>	<u>CALCULATION</u>
00	No calculation
01	E-LAMBDA * S- LAMBDA
02	E-LAMBDA * U-LAMBDA
03	E-LAMBDA * A-LAMBDA
04	E-LAMBDA * T-LAMBDA
05	E-LAMBDA * T-A-LAMBDA
06	E-LAMBDA * C-A-LAMBDA
07	E-LAMBDA * V-LAMBDA
08	E-LAMBDA * V*-LAMBDA
09	E-LAMBDA * B-LAMBDA
10	E-LAMBDA * X-BAR LAMBDA
11	E-LAMBDA * Y-BAR LAMBDA
12	E-LAMBDA * Z-BAR LAMBDA
13	E-LAMBDA * P-445
14	E-LAMBDA * P-535
15	E-LAMBDA * P-575

TABLE 2. Values of GENWEI - General Weighting Calculations.

# Technical Guide - Hazard Analysis of Broad-Band Optical Sources

<u>FUNCTION</u>	<u>FORTTRAN NAME</u>	<u>DESCRIPTION</u>
$V/\bar{E}_e$	VE	Radiant efficacy of radiation from $\lambda_{\min}$ to $\lambda_{\max}$ in lumens/watt; equals $(\sum_{\lambda} 680 E_{\lambda} V_{\lambda} \Delta\lambda) / E_e$
$V'/\bar{E}_e$	VIE	Fraction CIE scotopic radiation from $\lambda_{\min}$ to $\lambda_{\max}$ ; equals $(\sum_{\lambda} E_{\lambda} V'_{\lambda} \Delta\lambda) / E_e$
$\sum E^T / \bar{E}_e$	TRANS	Effective transmission of ocular media from $\lambda_{\min}$ to $\lambda_{\max}$ ; equals $(\sum_{\lambda} E_{\lambda} T_{\lambda} \Delta\lambda) / E_e$
	TRANTX	Effective transmission of ocular media multiplied by spectral absorption of ocular media; equals $(\sum_{\lambda} E_{\lambda} T_{\lambda} a_{\lambda} \Delta\lambda) / E_e$
$E_e / C_A$	EECA	ANSI laser MPE weighting factor for visible and IR-A; equals $(\sum_{\lambda} E_{\lambda} / C_{A\lambda} \Delta\lambda) / E_e$
	PCTUV	Percent of total irradiance between $\lambda_{\min}$ and $\lambda_{\max}$ which is UV radiation; equals $(100 \sum_{\lambda_{\min}}^{\lambda_{\max}} E_{\lambda} \Delta\lambda) / E_e$
	PCTVI	Percent of total irradiance which is visible radiation; equals $(100 \sum_{\lambda_{\min}}^{\lambda_{\max}} E_{\lambda} \Delta\lambda) / E_e$
	PCTNIR	Percent of total irradiance which is near radiation; equals $(100 \sum_{\lambda_{\min}}^{\lambda_{\max}} E_{\lambda} \Delta\lambda) / E_e$ -IR



# Technical Guide - Hazard Analysis of Broad-Band Optical Sources


<u>FUNCTION</u>	<u>FORTTRAN NAME</u>	<u>DESCRIPTION</u>
$B_{\lambda}$	BLUHAZ	Blue light hazard function weighted against spectral irradiance; equals $\sum_{\lambda} E_{\lambda} B_{\lambda} \Delta\lambda$
$\bar{X}_{\lambda}$	XBAR	CIE-1931 blue chromaticity coordinate weighted against spectral irradiance; equals $\sum_{\lambda} E_{\lambda} \bar{X}_{\lambda} \Delta\lambda$
$\bar{Y}_{\lambda}$	YBAR	CIE-1931 green chromaticity coordinate weighted against spectral irradiance; equals $\sum_{\lambda} E_{\lambda} \bar{Y}_{\lambda} \Delta\lambda$
$\bar{Z}_{\lambda}$	ZBAR	CIE-1931 red chromaticity coordinate weighted against spectral irradiance; equals $\sum_{\lambda} E_{\lambda} \bar{Z}_{\lambda} \Delta\lambda$
P-445	P445LB	Datnall nomogram absorption coefficient for blue weighted against spectral irradiance
P-535	P535LB	Datnall nomogram absorption coefficient for green weighted against spectral irradiance
P-575	P575LB	Datnall nomogram absorption coefficient for red weighted against spectral irradiance.

# Technical Guide - Hazard Analysis of Broad-Band Optical Sources

FUNCTION	FORTTRAN NAME	DESCRIPTION
$CF_A$	CF	Calibration factor; equals $(R_{vis}/E_{viscal})(DFV)$ for 250-1400 nm or 300-1400 nm; equals $(R_{uv}/E_{uvcal})(DFU)$ for 200-300 nm
$E_i$	EINSTR	Instrument readings for corroboration of input data in amperes.
$E_i(f_{ef\lambda}(\lambda))$	EIFOFX	Adjusted instrument readings; equals $E_i(f_{ef\lambda}(\lambda))$
$E_\lambda$	ELAMBD	Spectral irradiance of source under study; equals $E_i(f_{ef\lambda}(\lambda))/CF_A$
$L_\lambda$	LLAMBD	Spectral radiance of source under study; equals $E_\lambda/\Omega$
$E_\lambda \cdot F_\lambda(1)$	EFT	Spectral filter transmission for filter one; equals $(E_\lambda)(FT1)$
$E_\lambda \cdot F_\lambda(2)$	EFT	Spectral filter transmission for filter two; equals $(E_\lambda)(FT2)$
$\sum_{\lambda=1}^{\infty} E_\lambda \cdot F_\lambda(1,2)$	EFT	Spectral filter transmission for filter one and two together; equals $E_\lambda(FT1)(FT2)$
$E_r(\lambda)$	ERETLB	Spectral retinal irradiance for 3-mm and 7-mm pupil; equals $0.27 (L_\lambda \cdot T_\lambda \cdot D_p^2)$
$X_\lambda \cdot E_\lambda$	GLAMBD	General weighting column; ability to choose any previous function $X_\lambda$ in biodeck; equals $X_\lambda \cdot E_\lambda$



# Technical Guide - Hazard Analysis of Broad-Band Optical Sources



Technical Guide - Hazard Analysis of Broad-Band Optical Sources

APPENDIX B

COMPUTER LISTING

```

1*  C
2*  C  PROGRAM NAME  LASER MICROWAVE DIVISION SPECTRAL WEIGHTING PROGRAM
3*  C
4*  C  JUSTIFICATION  REQUESTED BY LASER MICROWAVE DIVISION  2 JAN 1976
5*  C                      BY DIV CHIEF ROBERT T. WANGEMANN
6*  C
7*  C  JOB NUMBER  UNASSIGNED AS OF 30 JUNE 1976
8*  C
9*  C  COMPUTER  UNIVAC 1108-EXEC 8
10* C
11* C  PROGRAMMER  ROBERT LEE SCHMITT
12* C
13* C  DATE COMPLETED  JUNE 1976
14* C
15* C  CHANGES  NONE
16* C
17* C  SUBROUTINES  INITIL
18* C                      INTERP
19* C                      SUM
20* C                      SUM1
21* C                      GLAMCO
22* C                      FILSUM
23* C                      SEQUEN
24* C                      PRICON
25* C                      HEADIN
26* C                      BDREAD
27* C                      HPLLOT
28* C
29* C  ABSTRACT  PROGRAM REDUCES SPECTRAL DATA TAKEN FROM VARIOUS BROADBAND
30* C                      OPTICAL SOURCES PRODUCING TABLES OF PERTINENT INFORMATION
31* C                      AND PLOT GRAPHS.
32* C
33* C  INPUT RECORD LAYOUT
34* C
35* C      SOURCE DESCRIPTION CARD
36* C
37* C      ONE OF TWO
38* C
39* C      1-78      DESCRIPTION
40* C
41* C      TWO OF TWO
42* C
43* C      1-72      DESCRIPTION
44* C
45* C
46* C      CALCULATION CONTROL CARD

```

47*	C		
48*	C		
49*	C	5	NUMBER OF FILTER S
50*	C	10	NUMBER OF DATA FIELDS FOR FILTER ONE
51*	C	15	NUMBER OF DATA FIELDS FOR FILTER TWO
52*	C	20-65 BY 5	FILTER CALCULATIONS
53*	C	70	NUMBER OF FIELDS FOR CALIBRATION DATA
54*	C	74.75	GENERAL WEIGHTING FUNCTION
55*	C		
56*	C		DISTANCE FACTOR CARD
57*	C		
58*	C	1-9	DISTANCE FACTOR FOR ULTRAVIOLET LIGHT
59*	C	10-18	DISTANCE FACTOR FOR VISIBLE LIGHT
60*	C		
61*	C		
62*	C		GENERAL DATA CARD
63*	C		
64*	C	1-4	WAVE LENGTH
65*	C	9-17	DATA---- WHERE DATA IS CALIBRATION
66*	C		FACTOR, B-LAMBDA , X-BAR LAMBDA , Y-BAR
67*	C		LAMBDA , Z-BAR LAMBDA , P445 LAMBDA ,
68*	C		P535 LAMBDA , P575 LAMBDA , COMPUTED
69*	C		FILTER DATA , DATA READINGS
70*	C		
71*	C		FILTER DATA IN RAW FORM
72*	C		
73*	C	1-4	WAVE LENGTH
74*	C	9-17	DIVIDEND
75*	C	25-33	DIVISOR
76*	C		
77*	C		BIO-DECK
78*	C		
79*	C	1-4	WAVE LENGTH
80*	C	5-13	S-LAMBDA
81*	C	14-22	U-LAMBDA
82*	C	23-31	V-LAMBDA
83*	C	32-40	VP-LAMBDA
84*	C	41-49	T-LAMBDA
85*	C	50-58	TA-LAMBDA
86*	C	59-67	CA-LAMBDA
87*	C	68-76	A-LAMBDA
88*	C		
89*	C		EVENT NAME CARD
90*	C		
91*	C	1-18	EVENT NAME
92*	C		
93*	C		SOURCE SOLID ANGLE CARD
94*	C		
95*	C	1-9	OMEGA
96*	C		
97*	C		
98*	C		END CARD
99*	C		
100*	C	1-3	END
101*	C		
102*	C		
103*	C		

104*	C	PRINTER LAYOUT	
105*	C		
106*	C	2-6	WAVE LENGTH
107*	C	9-17	CALIBRATION FACTOR
108*	C	20-28	INSTRUMENT READINGS
109*	C	31-39	ADJUSTED INSTRUMENT READINGS
110*	C	42-50	SPECTRAL IRRADIANCE OF SOURCE
111*	C	53-61	SPECTRAL RADIANCE OF SOURCE
112*	C	64-72	3-MM SPECTRAL-RETINAL IRRADIANCE
113*	C	75-83	7-MM SPECTRAL-RETINAL IRRADIANCE
114*	C	86-94	GENERAL WEIGHTING FUNCTION RESULTS
115*	C	97-105	SPECTRAL FILTER TRANSMISSIONS FOR FILTER ONE
116*	C	108-116	SPECTRAL FILTER TRANSMISSIONS FOR FILTER TWO
117*	C	119-127	SPECTRAL FILTER TRANSMISSIONS FOR BOTH FILTERS
118*	C		
119*	C	SINGLE WAVE CALCULATIONS	
120*	C		
121*	C	3-96	RESULT DESCRIPTION
122*	C	100-108	RESULT
123*	C		
124*	C	FILE RS\$SWP-PLOT LAY OUT	
125*	C		
126*	C	1-9	ELAMBDA
127*	C		
128*	C		
129*	C		
130*	C		
131*	C	BIODECK TABLES	
132*	C		
133*		REAL	SLAMBD(1340,2) @ ACGIH UV HAZARD ENVELOPE FUNCTION
134*		REAL	ULAMBD(1340,2) @ 1936 CIE UV SKIN ERYTHEMA ACTION SPECTRUM
135*		REAL	ALAMBD(1340,2) @ ANSI Z136 LASER WEIGHTING-UV HAZARD FUNCTION
136*		REAL	TLAMBD(1340,2) @ OCULAR MEDIA TRANSMISSION
137*		REAL	TALAMB(1340,2) @ ABSORPTION IN THE RETINA
138*		REAL	CALAMB(1340,2) @ RECIPROCAL OF ANSI-NEAR-INFRARED RETINAL
139*	C		BURN CORRECTION FACTOR
140*		REAL	VLAMBD(1340,2) @ CIE-1970 PHOTOPIC VISIBILITY FUNCTION
141*		REAL	VPLAMB(1340,2) @ CIE-1970 SCOTOPIC VISIBILITY FUNCTION
142*		REAL	BLAMBD(1340,2) @ ACGIH BLUE-LIGHT HAZARD FUNCTION
143*		REAL	XBLAMB(1340,2) @ CIE-1931 BLUE CHROMATICITY COORDINATE
144*		REAL	YBLAMB(1340,2) @ CIE-1931 GREEN CHROMATICITY COORDINATE
145*		REAL	ZBLAMB(1340,2) @ CIE-1931 RED CHROMATICITY COORDINATE
146*		REAL	P445LB(1340,2) @ DARTNALL NOMOGRAM ABSORPTION COEFFICIENT BLUE
147*		REAL	P535LB(1340,2) @ DARTNALL NOMOGRAM ABSORPTION COEFFICIENT GREEN
148*		REAL	P575LB(1340,2) @ DARTNALL NOMOGRAM ABSORPTION COEFFICIENT RED
149*	C		
150*	C	END BIODECK TABLES	
151*	C		
152*		REAL	DFV @ DISTANT FACTOR TO ADJUST VISIBLE RADIATION
153*	C		CALIBRATION FACTOR
154*		REAL	DFU @ DISTANT FACTOR TO ADJUST UV RADIATION
155*	C		CALIBRATION FACTOR
156*		REAL	DP(2) @ PUPIL SIZE USED IN RETINA CALCULATIONS
157*		REAL	OMEGA @ SOURCE SOLID ANGLE FOR SPECTRAL READINGS
158*		REAL	EINSTR(1340,2) @ SPECTRAL READINGS OF SOURCE UNDER STUDY
159*		REAL	FOFX(1340,2) @ FUNCTION TO MODIFY INSTRUMENT READINGS
160*		REAL	CF(1340,2) @ CALIBRATION FACTOR



161*		REAL	ETFOFX(340.2)	2 ADJUSTED INSTRUMENT READINGS
162*		REAL	ELAMBD(340.2)	2 SPECTRAL IRRADIANCE OF SOURCE UNDER STUDY
163*		REAL	LLAMBD(340.2)	2 SPECTRAL RADIANCE OF SOURCE UNDER STUDY
164*		REAL	ERETLB(340.3)	2 SPECTRAL-RETINAL IRRADIANCE FOR 3 AND 7-MM PUPIL
165*		REAL	EDELLB	2 TOTAL SPECTRAL IRRADIANCE OF SOURCE
166*		REAL	LDELLB	2 TOTAL RADIANCE OF SOURCE
167*		REAL	ACGIH	2 EFFECTIVE UV RADIATION ACCORDING TO THE
168*	C			ACGIH STANDARD ACTION SPECTRUM
169*		REAL	CIE	2 EFFECTIVE UV RADIATION ACCORDING TO THE
170*	C			1936 CIE UV ERYTHEMA ACTION SPECTRUM
171*		REAL	ANSI	2 EFFECTIVE UV RADIATION ACCORDING TO THE
172*	C			ANSI-Z136 LASER WEIGHTING UV HAZARD FUNCTION
173*		REAL	BLUMAZ	2 BLUE LIGHT HAZARD FUNCTION WEIGHTED AGAINST
174*	C			SPECTRAL IRRADIANCE
175*		REAL	XBAR	2 1931 BLUE CHROMATICITY COORDINATES WEIGHTED
176*	C			AGAINST SPECTRAL IRRADIANCE
177*		REAL	YBAR	2 1931 GREEN CHROMATICITY COORDINATES WEIGHTED
178*	C			AGAINST SPECTRAL IRRADIANCE
179*		REAL	ZBAR	2 1931 RED CHROMATICITY COORDINATES WEIGHTED
180*	C			AGAINST SPECTRAL IRRADIANCE
181*		REAL	P445	2 DARTNELL NOMOGRAM ABSORPTION COEFFICIENT FOR
182*	C			BLUE WEIGHTED AGAINST SPECTRAL IRRADIANCE
183*		REAL	P535	2 DARTNELL NOMOGRAM ABSORPTION COEFFICIENT FOR
184*	C			GREEN WEIGHTED AGAINST SPECTRAL IRRADIANCE
185*		REAL	P575	2 DARTNELL NOMOGRAM ABSORPTION COEFFICIENT FOR
186*	C			RED WEIGHTED AGAINST SPECTRAL IRRADIANCE
187*		REAL	VE	2 RADIANT EFFICACY OF RADIATION FROM LAMBDA-MIN
188*	C			TO LAMBDA-MAX
189*		REAL	VIE	2 FRACTION CIE SCOTOPIC RADIATION FROM LAMBDA-MIN
190*	C			TO LAMBDA-MAX
191*		REAL	TRANS	2 EFFECTIVE TRANSMISSION OF OCULAR MEDIA FROM
192*	C			LAMBDA-MIN TO LAMBDA-MAX
193*		REAL	TRANTX	2 EFFECTIVE TRANSMISSION OF OCULAR MEDIA
194*	C			MULTIPLIED BY SPECTRAL ABSORPTION OF OCULAR
195*	C			MEDIA
196*		REAL	EECA	2 ANSI LASER MPE WEIGHTING FACTOR FOR VIS+BLE
197*	C			AND INFRARED-A
198*		REAL	PCTUV	2 PERCENT OF TOTAL IRRADIANCE WHICH IS UV
199*	C			RADIATION
200*		REAL	PCTVI	2 PERCENT OF TOTAL IRRADIANCE WHICH IS VISIBLE
201*	C			RADIATION
202*		REAL	PCTNIR	2 PERCENT OF TOTAL IRRADIANCE WHICH IS NEAR
203*	C			INFRARED RADIATION
204*		REAL	ILLUM	2 ILLUMINANCE IN LAMENS PER SQUARE CENTIMETER
205*		REAL	LUMIN	2 LUMINANCE IN CANDELAS PER SQUARE CENTIMETER
206*		REAL	DATA	2 INPUT BUFFER FOR TABLE DATA
207*		REAL	DATA1	2 INPUT BUFFER FOR TABLE DATA
208*		REAL	WAVE	2 WAVELENGTH ASSOCIATED WITH DATA AND DATA1
209*		REAL	FT1(340.2)	2 FILTER ONE DATA TABLE
210*		REAL	FT2(340.2)	2 FILTER TWO DATA TABLE
211*		REAL	EFT(340.4)	2 SPECTRAL FILTER TRANSMISSION FOR FILTER ONE AND
212*	C			FILTER TWO AND FOR BOTH FILTERS
213*		REAL	FILTER(9)	2 EFFECTIVE UV IRRADIANCE ACCORDING TO THE
214*	C			THREE ACTION SPECTRA THROUGH EITHER FILTER
215*	C			OR BOTH FILTERS
216*		REAL	GLAMBD(340.2)	2 GENERAL WEIGHTING TABLE
217*		REAL	DELTA(340)	2 TABLE OF WAVE LENGTH INCREMENTS FOR EINSTR DATA

```

218*      REAL      PREV      @ DURING INPUT OF READINGS,CONTAINS THE
219*      C                                     VALUE OF THE LAST CARD READ
220*      INTEGER    LAMBDA(3,2)
221*      INTEGER    FLTCNT(3,2)
222*      INTEGER    CAL
223*      INTEGER    GENFUN      @ INDICATES WHETHER GENERAL FUNCTION DATA
224*      C                                     IS TO BE READ
225*      INTEGER    GENWEI      @ THE GENERAL WEIGHTING FUNCTION TO CALCULATE
226*      INTEGER    FILCAL(9)   @ INDICATES WHICH FILTER CALCULATIONS ARE TO
227*      C                                     BE PERFORMED
228*      INTEGER    CALHDR(14)  @ DESCRIPTION OF CALIBRATION DATA
229*      INTEGER    DESCRP(28)  @ DESCRIPTION OF SOURCE UNDER STUDY
230*      INTEGER    NUMFIL      @ NUMBER OF FILTER
231*      INTEGER    NOCOF1      @ NUMBER OF DATA FIELDS FOR FILTER ONE
232*      INTEGER    NOCOF2      @ NUMBER OF DATA FIELDS FOR FILTER TWO
233*      INTEGER    GENERL
234*      INTEGER    CALDAT      @ INDICATES WHETHER CALIBRATION DATA WILL BE INPUT
235*      C                                     AS RAW DATA OR CALCULATED DATA
236*      INTEGER    EVENT(3)    @ EVENT NUMBER OF RUN DATA READINGS
237*      INTEGER    EVENT2(12)
238*      INTEGER    PAGE        @ PAGE COUNT FOR LISTING
239*      INTEGER    DATE(2)     @ DATE OF THE RUN
240*      INTEGER    ENDMK        @ INDICATE WHETHER DATA SET WAS ENDED CORRECTLY
241*      INTEGER    PRTLAM(16,3) @ USED IN LIST HEADING FOR GENERAL WEIGHTING
242*      C                                     FUNCTION COLUMN
243*      INTEGER    LSTWAV      @ CONTAINS LAST WAVE LENGTH DURING CALCULATIONS
244*      INTEGER    PEAK        @ INPUT THAT INDICATES WHETHER VALUE IS A
245*      C                                     PEAK VALUE
246*      INTEGER    BANPAS(3)    @ BAND PASS WITH USED WHEN COMPUTING WITH
247*      C                                     PEAK VALUE
248*      INTEGER    FWAVE
249*      DATA (BANPAS(I),I=1,3)/ 3,5,10/
250*      DATA ((PRTLAM(I,J),J=1,3),I=1,16)/
251*      1* (NOT ' ',USED) ' ', ' '
252*      2* (S-L', 'AMBDA)' ' ', ' '
253*      3* (U-L', 'AMBDA)' ' ', ' '
254*      4* (A-L', 'AMBDA)' ' ', ' '
255*      5* (T-L', 'AMBDA)' ' ', ' '
256*      6* (T-A-', 'LAMBDA)' ' ', ' '
257*      7* (C-A-', 'LAMBDA)' ' ', ' '
258*      8* (V-L', 'AMBDA)' ' ', ' '
259*      9* (V-L', 'AMBDA)' ' ', ' '
260*      A* (B-L', 'AMBDA)' ' ', ' '
261*      B* (X-BAR', 'LAMBDA)' 'A' ' ', ' '
262*      C* (Y-BAR', 'LAMBDA)' 'A' ' ', ' '
263*      D* (Z-BAR', 'LAMBDA)' 'A' ' ', ' '
264*      E* (P-', '445)' ' ', ' '
265*      F* (P-', '535)' ' ', ' '
266*      G* (P-', '575)' ' ', ' '
267*      DATA ((LAMBDA(I,J),J=1,2),I=1,3)/
268*      1 'S-LA' , 'MBDA' ,
269*      2 'U-LA' , 'MBDA' ,
270*      3 'A-LA' , 'MBDA' /
271*      DATA ((FLTCNT(I,J),J=1,2),I=1,3)/
272*      1 'FILTE' , 'R ONE' ,
273*      2 'FILTE' , 'R TWO' ,
274*      3 'BOTH F' , 'ILTERS' /

```

```

275*      DATA EVENT2 / 'FIGURE', 'A', 'B SOLUT', 'E SPEC', 'TRAL I',
276*      1 'RRADIA', 'NCE AT', 'C', 'M FOR', ' ', ' ', ' ', ' /
277*      2      CONTINUE
278*      DP(1) = .09      a .3CM SQUARED
279*      DP(2) = .49      a .7CM SQUARED
280*      WAVE = 200
281*      C
282*      C      INITIALIZE GENERAL FUNCTION TO UNITY. IF ANOTHER FUNCTION IS DESIRED
283*      C      IT WILL BE INPUT BY CARDS AND AFFECT ONLY THE SPECIFIED RANGES
284*      C
285*      DO 5 I = 1,240
286*      FOFX(I,1) = WAVE
287*      FOFX(I,2) = 1
288*      WAVE = WAVE + 5
289*      5 CONTINUE
290*      C
291*      C      READ SOURCE DESCRIPTION
292*      C
293*      READ 10, (DESCRP(I), I=1,14)
294*      READ 10, (DESCRP(I), I=15,28)
295*      10 FORMAT(13A6,A2)
296*      C
297*      C      READ CALCULATION CONTROL CARD
298*      C
299*      READ 30, NUMFIL, NOCOF1, NOCOF2, FIL CAL, CALDAT, GENWEI, GENFUN
300*      30 FORMAT(15I5)
301*      C
302*      C      READ THE CALIBRATION DATA
303*      C
304*      READ 40, DFU, DFV
305*      40 FORMAT(2F9,2)
306*      ITCAL = CALDAT + 1
307*      GO TO (45, 130, 126), ITCAL
308*      C
309*      C      45-- CALIBRATION IS RAW, CF IS TO BE CALCULATED.
310*      C      130- CALIBRATION IS PRE-CALCULATED.
311*      C      126- CALIBRATION IS ALL ONE'S, PROGRAM GENERATES TABLE.
312*      C
313*      45 READ 35, CALHDR
314*      35 FORMAT(13A6,A2)
315*      C
316*      C      THE CALIBRATION INPUT IS THE RAW DATA AND CF MUST BE COMPUTED
317*      DO 60 I = 1,341
318*      READ(5,50,ERR=70) CF(I,1), CF(I,2)
319*      50 FORMAT(F4,0,T9,E9,2)
320*      60 CONTINUE
321*      70 READ(10,80) ENDMK
322*      80 FORMAT(A3)
323*      IF (ENDMK .EQ. 'END') GOTO 100
324*      PRINT 90
325*      90 FORMAT('0', 'CALIBRATION DATA NOT ENDED CORRECTLY')
326*      STOP
327*      100 DO 110 J = 1,341
328*      READ(5,50,ERR=120) WAVE, DATA
329*      IF (IFIX(WAVE+0.01) .EQ. IFIX(CF(J,1)+0.01)) GOTO 96
330*      PRINT 95, WAVE
331*      95      FORMAT('0 WAVE LENGTH ', F5,0, ' OF SPECTRAL IRRADIANCE DOES',

```

```

332*      1      'NOT MATCH WAVE LENGTH OF READING FOR CALIBRATION'
333*      2      'FACTOR.')
334*      STOP
335*      96     IF(DATA .NE. 0) GOTO 98
336*      PRINT 99,WAVE
337*      99     FORMAT('D DIVISION BY ZERO IN CALIBRATION FACTOR SECTION AT',
338*      1      'WAVE LENGTH ',F5.0)
339*      STOP
340*      98     IF(WAVE .GT. 300) GOTO 97
341*      CF(J,2) = CF(J,2) / DATA * DFU
342*      GOTO 110
343*      97     CF(J,2) = CF(J,2) / DATA * DFV
344*      110 CONTINUE
345*      120 IF(I .EQ. J) GOTO 125
346*      PRINT 121
347*      121     FORMAT('D CALIBRATION FACTOR ERROR - NUMBER RAW DATA NOT MATCHED')
348*      STOP
349*      125     READ(0,80) ENDMK
350*      IF(ENDMK .EQ. 'END') GOTO 170
351*      PRINT 90
352*      STOP
353*      C
354*      C GENERATE CF TABLE FROM 200-1400(WAVELENGTHS)--ALL VALUES = 1.
355*      126 CONTINUE
356*      VAL=195
357*      DO 127 I=1,341
358*      CF(I,1)=VAL*5
359*      VAL=CF(I,1)
360*      CF(I,2)=1.0
361*      127 CONTINUE
362*      GO TO 170
363*      C
364*      C READ COMPUTED CALIBRATION DATA
365*      C
366*      130 READ 35,CALHDR
367*      DO 150 I = 1,341
368*      READ(5,140,ERR=160) (CF(I,J),J=1,2)
369*      140 FORMAT(F4.0,T9,E9.2)
370*      IF(CF(I,1) .GT. 300) GOTO 135
371*      CF(I,2) = CF(I,2) * DFU
372*      GOTO 150
373*      135 CF(I,2) = CF(I,2) * DFV
374*      150 CONTINUE
375*      160 READ(0,80) ENDMK
376*      IF(ENDMK .EQ. 'END') GOTO 170
377*      PRINT 90
378*      STOP
379*      170 CONTINUE
380*      C
381*      C READ BIODECK
382*      C
383*      DO 190 I = 1,341
384*      READ(5,180,ERR=200) WAVE,SLAMBD(I,2),ULAMBD(I,2),VLAMBD(I,2),
385*      1VPLAMBD(I,2),TLAMBD(I,2),TALAMBD(I,2),CALAMBD(I,2),ALAMBD(I,2)
386*      180 FORMAT(F4.0,8E9.2)
387*      SLAMBD(I,1) = WAVE
388*      ULAMBD(I,1) = WAVE

```



```

389•      VLAMB(I,1) = WAVE
390•      VPLAMB(I,1) = WAVE
391•      TLAMB(I,1) = WAVE
392•      TALAMB(I,1) = WAVE
393•      CALAMB(I,1) = WAVE
394•      ALAMB(I,1) = WAVE
395•      190 CONTINUE
396•      200 READ(0,210) ENDMK
397•      210 FORMAT(A3)
398•      IF(ENDMK.EQ.'END') GOTO 230
399•      PRINT 220,I
400•      220 FORMAT('D','BIODECK HAS NO END CARD AT IMAGE ',I3)
401•      STOP
402•      230 CONTINUE
403•      C
404•      C
405•      CALL BDREAD(1BLAMB)
406•      CALL BDREAD(XBLAMB)
407•      CALL BDREAD(Y3LAMB)
408•      CALL BDREAD(Z3LAMB)
409•      CALL BDREAD(P445LB)
410•      CALL BDREAD(P535LB)
411•      CALL BDREAD(P575LB)
412•      C
413•      C   READ FILTER TRANSMISSION FUNCTION(S), IF ANY
414•      C   FILTER TWO DATA IS READ FIRST.
415•      C
416•      I = NUMFIL + 1
417•      GOTO(450,290,390),I
418•      C
419•      C   DETERMINE NUMBER OF DATA FIELDS FOR FILTER ONE
420•      C
421•      290 GOTO(300,360),NOCOF1
422•      C
423•      C   ONE DATA FIELD FOR FILTER ONE
424•      C
425•      300 DO 320 I = 1,341
426•      READ(5,310,ERR=330)(FT1(I,K),K=1,2)
427•      310 FORMAT(F4.0,T3,E9.2)
428•      320 CONTINUE
429•      330 READ(0,340) ENDMK
430•      340 FORMAT(A3)
431•      IF(ENDMK.EQ.'END') GOTO 450
432•      345 PRINT 350
433•      350 FORMAT('D','FILTER DATA WAS NOT ENDED CORRECTLY')
434•      STOP
435•      C
436•      C   TWO DATA FIELDS FOR FILTER ONE
437•      C
438•      360 DO 380 I = 1,341
439•      READ(5,370,ERR=330) FT1(I,1),DATA,DATA1
440•      370 FORMAT(F4.0,T9,2E9.2)
441•      FT1(I,2) = DATA / DATA1
442•      380 CONTINUE
443•      GOTO 345
444•      C
445•      C   DETERMINE NUMBER OF DATA FIELDS FOR FILTER TWO

```

```

446*      C
447*      390 GOTO(400,430),NOCOF2
448*      C
449*      C      ONE DATA FIELD FOR FILTER TWO
450*      C
451*      400 DO 410 I = 1,341
452*          READ(5,310,ERR=420)(FT2(I,K),K=1,2)
453*      410 CONTINUE
454*          GOTO 345
455*      420 READ(10,340) ENDMK
456*          IF(ENDMK.EQ.'END') GOTO 290
457*          GOTO 345
458*      C
459*      C      TWO DATA FIELDS FOR FILTER TWO
460*      C
461*      430 DO 440 I = 1,341
462*          READ(5,370,ERR=420) FT2(I,1),DATA,DATA1
463*          FT2(I,2) = DATA / DATA1
464*      440 CONTINUE
465*          GOTO 345
466*      C
467*      C      READ GENERAL FUNCTION. INPUT CONTAINS THE FIRST AND LAST WAVE LENGTH
468*      C      AFFECTED BY FUNCTION
469*      C
470*      450 IF(GENFUN.EQ.0) GOTO 520
471*          READ(5,460,ERR=480) FWAVE,LWAVE,DATA
472*      460 FORMAT(I4,T10,I4,T20,E9.2)
473*      C
474*      C      DETERMINE THE TABLE ELEMENT NUMBERS FOR THE WAVE LENGTH INTERVALS
475*      C
476*          J = (FWAVE - 200) / 5 + 1
477*          K = (LWAVE - 200) / 5 + 1
478*      C
479*      C      INSERT THE FUNCTION INTO THE CORRECT ELEMENTS OF THE GENERAL FUNCTION
480*      C      TABLE
481*      C
482*          DO 465 L = J,K
483*              FOFX(L,2) = DATA
484*      465 CONTINUE
485*          GOTO 520
486*      480 PRINT 510
487*      510 FORMAT('D','INCORRECT GENERAL FUNCTION CARD')
488*          STOP
489*      520 CONTINUE
490*          CALL IDENT
491*      C
492*      C      READ SPECTRAL DATA OF SOURCE UNDER STUDY
493*      C
494*      C      READ THE EVENT NUMBER OF THE DATA
495*      C
496*      530 READ(5,540,END=9999) EVENT
497*      540 FORMAT(I3A6)
498*      C
499*      IF (EVENT(1).EQ.'NEXT') GO TO 2
500*      C      READ SOURCE SOLID ANGLE
501*      C
502*      READ 550,OMEGA

```

```

503*      550 FORMAT(E9.2)
504*      C
505*      C      READ THE DATA READINGS
506*      C
507*      PREV = 0
508*      DO 570 I = 1,341
509*      555 READ(5,560,ERR=580) (EINSTR(I,K),K=1,2),PEAK
510*      560 FORMAT(F4.0,T9,E9.2,T20,A4)
511*      C
512*      C      IF PRESENT WAVE LENGTH IS LESS THAN OR EQUAL TO THE PREVIOUS WAVE
513*      C      LENGTH DISREGARD IT AND READ THE NEXT CARD
514*      C
515*      IF(PREV .LT. EINSTR(I,1)) GOTO 561
516*      PRINT 562,(EINSTR(I,K),K=1,2)
517*      562 FORMAT(' SOURCE DATUM DISREGARDED - ',F4.0,E9.2)
518*      GOTO 555
519*      561 PREV = EINSTR(I,1)
520*      C
521*      C      IF THE VALUE IS A PEAK VALUE THEN NEGATE THE WAVE LENGTH TO INDICATE
522*      C      THAT THE VALUE ASSOCIATED WITH THIS WAVE LENGTH IS A PEAK VALUE
523*      C
524*      IF(PEAK .EQ. 'PEAK') EINSTR(I,1) = EINSTR(I,1) * (-1)
525*      570 CONTINUE
526*      GOTO 600
527*      580 READ(10,590) ENDMK
528*      590 FORMAT(A3)
529*      IF(ENDMK .EQ. 'END') GOTO 620
530*      600 PRINT 610
531*      610 FORMAT('0','SPECTRAL READINGS WERE NOT ENDED CORRECTLY')
532*      STOP
533*      620 CONTINUE
534*      MAXELM=I-1
535*      C
536*      C      COMPUTE THE DELTA ASSOCIATED WITH EACH WAVE LENGTH. THIS IS DONE
537*      C      IN THE FOLLOWING WAY:
538*      C
539*      C      1) DETERMINE THE DELTA FOR THE FIRST WAVE LENGTH. IF THE WAVE
540*      C      LENGTH IS LESS THAN ZERO, IT IS A PEAK AND DELTA IS SET TO CORRECT
541*      C      BANPAS VALUE. IF IT IS NOT A PEAK THEN DELTA EQUALS ONE HALF OF
542*      C      THE DIFFERENCE BETWEEN THE FIRST TWO CONSECUTIVE NON-PEAK WAVE
543*      C      LENGTHS
544*      C
545*      C      2) COMPUTE THE REST OF THE DELTAS. PEAK VALUES GET THE CORRECT
546*      C      BANPAS VALUE. FOR NON-PEAK VALUES, MUST KEEP TRACK OF LAST
547*      C      NON-PEAK WAVE LENGTH AND THE WAVE LENGTH INTERVAL. ALSO MUST
548*      C      KNOW IF THE LAST VALUE WAS A PEAK THAT FELL ON A WAVE INTERVAL
549*      C      WHICH WILL BE TREATED HAS A NON-PEAK FOR THE NEXT NON-PEAK DELTA
550*      C      VALUE. SO DELTA FOR NON PEAK VALUE IS THE DIFFERENCE BETWEEN
551*      C      THE PRESENT WAVE LENGTH AND THE PREVIOUS NON-PEAK WAVE LENGTH.
552*      C
553*      IF(EINSTR(1,1).LT.0) GOTO 623
554*      DIV = 2
555*      WAVE1 = EINSTR(1,1)
556*      LMN = 3
557*      WAVE2 = EINSTR(2,1)
558*      IJK = 2
559*      619 DO 621 I =      LMN,MAXELM

```

```

560*      IF(WAVE1 .GT. 0 .AND. WAVE2 .GT. 0) GOTO 622
561*      WAVE1 = WAVE2
562*      WAVE2 = EINSTR(I,1)
563*      621 CONTINUE
564*      C
565*      C      COME HERE WHEN TWO CONSECUTIVE NON PEAK VALUES ARE FOUND AND COMPUTE
566*      C      DELTA FOR FIRST NON-PEAK VALUE
567*      C
568*      622 DELTA(I) = (WAVE2 - WAVE1) / DIV
569*      LSTWAV = EINSTR(IJK-1,1)      @ LAST NON-PEAK WAVE LENGTH
570*      INTVL = DELTA(I) * DIV        @ INTERVAL BETWEEN 2 CONSECUTIVE NON-PEAKS
571*      GOTO 626
572*      C
573*      C      FIRST VALUE IS A PEAK SO DO LOOP UNTIL A NON-PEAK VALUE IS FOUND
574*      C
575*      623 DO 624 J = 1, MAXELM
576*      DELTA(J) = BANPAS(3)
577*      IF(EINSTR(J,1) .GT. -700) DELTA(J) = BANPAS(2)
578*      IF(EINSTR(J,1) .GT. -400) DELTA(J) = BANPAS(1)
579*      IF(EINSTR(J+1,1) .GT. 0) GOTO 625
580*      624 CONTINUE
581*      625 DIV = 1
582*      IJK = J+2
583*      WAVE 1 = EINSTR(J+1,1)
584*      WAVE2 = EINSTR(J+2,1)
585*      LMN = J + 3
586*      GOTO 619
587*      C
588*      C      PROGRAM GOT HERE AFTER IT HAS DETERMINE DELTA FOR THE FIRST NON-PEAK
589*      C      VALUE AND ANY PEAK VALUE THAT WAS BEFORE IT
590*      C
591*      626 DO 629 I = IJK, MAXELM
592*      IF(EINSTR(I,1)) 627, 631, 528
593*      C
594*      C      PRESENT VALUE IS A PEAK. IF PEAK IS ON A NON-PEAK INTERVAL THEN
595*      C      PEAK WAVE BECOMES LAST WAVE LENGTH
596*      C
597*      627 IF ( EINSTR(I,1) - LSTWAV .EQ. INTVL ) LSTWAV = EINSTR(I,1)
598*      DELTA(I) = BANPAS(3)
599*      IF(EINSTR(I,1) .GT. -700) DELTA(I) = BANPAS(2)
600*      IF(EINSTR(I,1) .GT. -400) DELTA(I) = BANPAS(1)
601*      GOTO 629
602*      C
603*      C      PRESENT VALUE IS NON-PEAK
604*      C
605*      628 DELTA(I) = EINSTR(I,1) - LSTWAV
606*      LSTWAV = EINSTR(I,1)
607*      INTVL = DELTA(I)
608*      629 CONTINUE
609*      631 CONTINUE
610*      C
611*      C      CALCULATION SECTION FOLLOWS
612*      C
613*      C
614*      C      IT IS NOT NECESSARY THAT THE WAVE LENGTH INTERVAL OF THE SPECTRAL
615*      C      READINGS OR ANY OF INTERMEDIATE VALUES CORRESPOND TO THE WAVE
616*      C      LENGTH INTERVAL OF THE BIOLOGICAL DATA AND THE CALIBRATION DATA.

```



```

617* C      IT IS THEREFORE NECESSARY IN EACH CALCULATON SECTION TO MATCH UP
618* C      BIO AND CAL DATA WITH THE CORRESPONDING SPECTRAL AND INTERMEDIATE
619* C      RESULTS DATA. IF SPECTRAL READING FALL BETWEEN BIO DATA AND CAL
620* C      DATA THEN THE BIO AND CAL DATA WILL HAVE TO BE INTERPOLLATED FOR
621* C      THE WAVE LENGTH OF SPECTRAL DATA DO TO THE FACT THAT THE PROGRAM
622* C      NEGATES THE WAVE LENGTH OF PEAK READINGS IT IS NECESSARY WHEN
623* C      COMPARING WAVE LENGTHS TO USE THE ABSOLUTE VALUE OF THE WAVE
624* C      LENGTH FOR SPECTRAL READING DATA
625* C
626* C      CALCULATE ADJUSTED INSTRUMENT READINGS
627* C
628* C      K = 1
629* C      DO 640 I = 1,MAXELM
630* 633 IF(FOFX(K,1) .EQ. ABS(EINSTR(I,1))) GOTO 630
631* IF(ABS(EINSTR(I,1)) .LT. FOFX(K,1)) GOTO 630
632* K = K + 1
633* GOTO 633
634* 638 EIFOX(I,1) = ABS(EINSTR(I,1))
635* EIFOX(I,2) = EINSTR(I,2) * FOFX(K-1,2)
636* GOTO 640
637* 630 EIFOX(I,1) = ABS(EINSTR(I,1))
638* EIFOX(I,2) = EINSTR(I,2) * FOFX(K,2)
639* K = K + 1
640* 640 CONTINUE
641* C
642* C      CALCULATE SPECTRAL IRRADIANCE OF SOURCE UNDER STUDY
643* C
644* C      K = 1
645* C      DO 690 I = 1,MAXELM
646* 645 IF(EIFOX(I,1) .NE. CF(K,1)) GOTO 680
647* IF(CF(K,2) .NE. 0) GOTO 570
648* 650 PRINT 660,EIFOX(I,1)
649* 660 FORMAT('0 ATTEMPT TO DIVIDE A CALIBRATION FACTOR OF ZERO INTO ADJU
650* 1STEP INSTRUMENT READING AT WAVE LENGTH *F5.0)
651* STOP
652* 670 ELAMBD(I,1) = EIFOX(I,1)
653* ELAMBD(I,2) = EIFOX(I,2) / CF(K,2)
654* K = K + 1
655* GOTO 690
656* 680 IF(EIFOX(I,1) .LT. CF(K,1)) GOTO 685
657* K = K + 1
658* GOTO 645
659* 685 CALL INTERP(EIFOX,CF,I,K,CALFAC)
660* IF(CALFAC .EQ. 0) GOTO 650
661* ELAMBD(I,1) = EIFOX(I,1)
662* ELAMBD(I,2) = EIFOX(I,2) / CALFAC
663* 690 CONTINUE
664* C
665* C      CALCULATE SPECTRAL RADIANCE OF SOURCE UNDER STUDY
666* C
667* C      DO 700 I = 1,MAXELM
668* LLAMBD(I,1) = ELAMBD(I,1)
669* LLAMBD(I,2) = ELAMBD(I,2) / OMEGA
670* 700 CONTINUE
671* C
672* C      CALCULATE SPECTRAL-RETINAL IRRADIANCE FOR 3-MM AND 7-MM PUPILS
673* C

```

```

674*      K = 1
675*      DO 750 I = 1,MAXELM
676*      705 IF(ELAMBD(I,1) .NE. TLAMBD(K,1)) GOTO 720
677*      ERET(LB(I,1)) = ELAMBD(I,1)
678*      J = 2
679*      DO 710 L = 1,2
680*      ERET(LB(I,J)) = .27 * ELAMBD(I,2) * TLAMBD(K,2) * DP(L)
681*      J = J + 1
682*      710 CONTINUE
683*      K = K + 1
684*      GOTO 750
685*      720 IF(ELAMBD(I,1) .LT. TLAMBD(K,1)) GOTO 730
686*      K = K + 1
687*      GOTO 705
688*      730 CALL INTERP(ELAMBD,TLAMBD,I,K,TLRES)
689*      ERET(LB(I,1)) = ELAMBD(I,1)
690*      J = 2
691*      DO 740 L = 1,2
692*      ERET(LB(I,J)) = .27 * ELAMBD(I,2) * TLRES * DP(L)
693*      J = J + 1
694*      740 CONTINUE
695*      750 CONTINUE
696*      C
697*      C      CALCULATE SPECTRAL FILTER TRANSMISSION FOR ONE FILTER
698*      C
699*      IF(NUMFIL) 830,830,755
700*      755 K = 1
701*      DO 780 I = 1,MAXELM
702*      760 IF(ELAMBD(I,1) .NE. FT1(K,1)) GOTO 765
703*      FTRES = FT1(K,2)
704*      GOTO 775
705*      765 IF(ELAMBD(I,1) .LT. FT1(K,1)) GOTO 770
706*      K = K + 1
707*      GOTO 760
708*      770 CALL INTERP(ELAMBD,FT1,I,K,FTRES)
709*      775 EFT(I,1) = ELAMBD(I,1)
710*      EFT(I,2) = ELAMBD(I,2) * FTRES
711*      K = K + 1
712*      780 CONTINUE
713*      C
714*      C      CALCULATE SPECTRAL FILTER TRANSMISSION FOR TWO FILTER
715*      C
716*      GOTO(830,785),NUMFIL
717*      785 K = 1
718*      J = 1
719*      DO 825 I = 1,MAXELM
720*      790 IF(ELAMBD(I,1) .EQ. FT1(J,1)) GOTO 800
721*      IF(ELAMBD(I,1) .LT. FT1(J,1)) GOTO 795
722*      J = J + 1
723*      GOTO 790
724*      795 CALL INTERP(ELAMBD,FT1,I,J,FT1RES)
725*      GOTO 805
726*      800 FT1RES = FT1(J,2)
727*      805 IF(ELAMBD(I,1) .EQ. FT2(K,1)) GOTO 815
728*      IF(ELAMBD(I,1) .LT. FT2(K,1)) GOTO 810
729*      K = K + 1
730*      GOTO 805

```

```

731*      810 CALL INTERP(ELAMBD,FT2,I,K,FT2RES)
732*      GOTO 820
733*      815 FT2RES = FT2(K,2)
734*      820 EFT(I,3) = ELAMBD(I,2) * FT2RES
735*      EFT(I,4) = ELAMBD(I,2) * FT2RES * FTIRES
736*      K = K + 1
737*      J = J + 1
738*      825 CONTINUE
739*      830 CONTINUE
740*
741*      C
742*      C      DETERMINE IF A GENERAL WEIGHTING TABLE IS TO BE CALCULATED
743*      C
744*      GENERL = GENWEI + 1
745*      GOTO(860,870,880,890,900,910,920,930,940,950,960,970,980,990,1000,
746*      11010),GENERL
747*      860 GOTO 1020
748*      870 CALL GLAMCO(GLAMBD,ELAMBD,SLAMBD,$1020)
749*      880 CALL GLAMCO(GLAMBD,ELAMBD,ULAMBD,$1020)
750*      890 CALL GLAMCO(GLAMBD,ELAMBD,ALAMBD,$1020)
751*      900 CALL GLAMCO(GLAMBD,ELAMBD,TLAMBD,$1020)
752*      910 CALL GLAMCO(GLAMBD,ELAMBD,TALAMB,$1020)
753*      920 CALL GLAMCO(GLAMBD,ELAMBD,CALAMB,$1020)
754*      930 CALL GLAMCO(GLAMBD,ELAMBD,VLAMBD,$1020)
755*      940 CALL GLAMCO(GLAMBD,ELAMBD,VPLAMB,$1020)
756*      950 CALL GLAMCO(GLAMBD,ELAMBD,BLAMBD,$1020)
757*      960 CALL GLAMCO(GLAMBD,ELAMBD,XSLAMB,$1020)
758*      970 CALL GLAMCO(GLAMBD,ELAMBD,YSLAMB,$1020)
759*      980 CALL GLAMCO(GLAMBD,ELAMBD,ZSLAMB,$1020)
760*      990 CALL GLAMCO(GLAMBD,ELAMBD,P445LB,$1020)
761*      1000 CALL GLAMCO(GLAMBD,ELAMBD,P535LB,$1020)
762*      1010 CALL GLAMCO(GLAMBD,ELAMBD,P575LB,$1020)
763*      1020 CONTINUE
764*      DO 1040 I = 1,MAXELM
765*      IF (EINSTR(I,1)) 1030,1040,1040
766*      1030 ELAMBD(I,1) = EINSTR(I,1)
767*      LLAMBD(I,1) = EINSTR(I,1)
768*      1040 CONTINUE
769*      C
770*      C      CALCULATE TOTAL SPECTRAL IRRADIANCE FOR WAVE LIMITS USED FOR
771*      C      INSTRUMENT READINGS
772*      C
773*      ITEST = 0
774*      GOTO 1045
775*      1041 DO 1141 II=1,MAXELM
776*      1141 ELAMBD(II,2)=EFT(II,2)
777*      ITEST = 1
778*      GOTO 1045
779*      1042 DO 1142 II=1,MAXELM
780*      1142 ELAMBD(II,2)=EFT(II,3)
781*      ITEST = 2
782*      GOTO 1045
783*      1043 DO 1143 II=1,MAXELM
784*      1143 ELAMBD(II,2)=EFT(II,4)
785*      ITEST = 3
786*      1045 L = 1
787*      EDLLB = SUM1(ELAMBD,DELTA,L,MAXELM)
788*      C

```

788\* C CALCULATE RADIANCE OF SOURCE FROM LAMBDA-MIN TO LAMBDA-MAX  
 789\* C  
 790\* LDELLB = EDELLB/OMEGA  
 791\* C  
 792\* C CALCULATE EFFECTIVE ULTRAVIOLET RADIATION ACCORDING TO THE ACGIH  
 793\* C STANDARD ACTION SPECTRUM  
 794\* C  
 795\* ACGIH = SUM(ELAMB,SLAMB,DELTA)  
 796\* C  
 797\* C CALCULATE EFFECTIVE ULTRAVIOLET RADIATION ACCORDING TO THE 1936 CIE  
 798\* C ULTRAVIOLET ERYTHEMA ACTION SPECTRUM  
 799\* C  
 800\* CIE = SUM(ELAMB,ULAMB,DELTA)  
 801\* C  
 802\* C CALCULATE EFFECTIVE ULTRAVIOLET RADIATION ACCORDING TO THE ANSI-Z136  
 803\* C LASER WEIGHTING UV HAZARD FUNCTION  
 804\* C  
 805\* ANSI = SUM(ELAMB,ALAMB,DELTA)  
 806\* C  
 807\* C CALCULATE BLUE LIGHT HAZARD FUNCTION WEIGHTED AGAINST SPECTRAL IRRADIANCE  
 808\* C  
 809\* BLUHAZ = SUM(ELAMB,BLAMB,DELTA)  
 810\* C  
 811\* C BLUE, GREEN, RED 1931 CHROMATICITY COORDINATES WEIGHTED AGAINST  
 812\* C SPECTRAL IRRADIANCE  
 813\* C  
 814\* XBAR = SUM(ELAMB,XBLAMB,DELTA)  
 815\* YBAR = SUM(ELAMB,YBLAMB,DELTA)  
 816\* ZBAR = SUM(ELAMB,ZBLAMB,DELTA)  
 817\* C  
 818\* C DARTNALL NOMOGRAM ABSORPTION COEFFICIENT FOR BLUE, GREEN, RED  
 819\* C WEIGHTED AGAINST SPECTRAL IRRADIANCE  
 820\* C  
 821\* P445 = SUM(ELAMB,P445LB,DELTA)  
 822\* P535 = SUM(ELAMB,P535LB,DELTA)  
 823\* P575 = SUM(ELAMB,P575LB,DELTA)  
 824\* C  
 825\* C CALCULATE RADIANT EFFACACY OF RADIATION FROM LAMBDA-MIN TO LAMBDA-MAX  
 826\* C  
 827\* VE = 680 \* SUM(ELAMB,VLAMB,DELTA) / EDELLB  
 828\* C  
 829\* C CALCULATE FRACTION CIE SCOTOPIC RADIATION FROM LAMBDA-MIN TO LAMBDA-MAX  
 830\* C  
 831\* VIE = SUM(ELAMB,VPLAMB,DELTA) / EDELLB  
 832\* C  
 833\* C CALCULATE EFFECTIVE TRANSMISSION OF OCULAR MEDIA FROM MIN TO MAX LAMBDA  
 834\* C  
 835\* TRANS = SUM(ELAMB,TLAMB,DELTA) / EDELLB  
 836\* C  
 837\* C CALCULATE EFFECTIVE TRANSMISSION OF OCULAR MEDIA MULTIPLIED BY  
 838\* C SPECTRAL ABSORPTION OF OCULAR MEDIA  
 839\* C  
 840\* TRANTX = SUM(ELAMB,TALAMB,DELTA) / EDELLB  
 841\* C  
 842\* C CALCULATE ANSI LASER MPE WEIGHTING FACTOR FOR VISIBLE AND INFRARED-A  
 843\* C  
 844\* EECA = SUM(ELAMB,CALAMB,DELTA) / EDELLB



```

845*      ILLUM = EDELLB * VE
846*      LUMIN = ILLUM / OMEGA
847*
848*      C      CALCULATE PERCENT OF TOTAL IRRADIANCE WHICH IS ULTRAVIOLET RADIATION
849*      L = 1
850*      I = 0
851*      PCTUV = 0
852*      IF (ELAMBD(I,1) .GT. 400) GOTO 1070
853*      DO 1050 I = 1, MAXELM
854*      IF (ELAMBD(I,1) .GT. 400) GOTO 1060
855*      1050 CONTINUE
856*      1060 IF (ELAMBD(I,1) .GT. 400) I = I - 1
857*      PCTUV = 100 * SUM1(ELAMBD, DELTA, L, I) / EDELLB
858*      1070 CONTINUE
859*
860*      C      CALCULATE PERCENT OF TOTAL IRRADIANCE WHICH IS VISIBLE RADIATION
861*
862*      IF (I .EQ. MAXELM) GOTO 1110
863*      MINELM = I + 1
864*      IF (MINELM .LE. 1) MINELM = 1
865*      PCTVI = 0
866*      IF (ELAMBD(I,1) .GT. 700) GOTO 1100
867*      DO 1080 I = MINELM, MAXELM
868*      IF (ELAMBD(I,1) .GT. 700) GOTO 1090
869*      1080 CONTINUE
870*      1090 IF (ELAMBD(I,1) .GT. 700) I = I - 1
871*      PCTVI = 100 * SUM1(ELAMBD, DELTA, MINELM, I) / EDELLB
872*      1100 CONTINUE
873*
874*      C      CALCULATE PERCENT OF TOTAL IRRADIANCE WHICH IS NEAR INFRARED
875*
876*      IF (I .EQ. MAXELM) GOTO 1110
877*      MINELM = I + 1
878*      IF (MINELM .LE. 1) MINELM = 1
879*      PCTNIR = 0
880*      PCTNIR = 100 * SUM1(ELAMBD, DELTA, MINELM, MAXELM) / EDELLB
881*      1110 IF (ITEST .NE. 0) GOTO 1515
882*
883*      C      CALCULATE TOTAL SPECTRAL IRRADIANCE WEIGHTED SPECTRALLY AGAINST
884*      C      THE TRANSMISSION OF FILTER ONE, FILTER TWO AND BOTH FILTERS
885*
886*      C
887*      EE1 = 0
888*      EE2 = 0
889*      EEFIG2 = 0
890*      IF (NUMFIL) 1330, 1330, 1170
891*      1170 GOTO (1180, 1200), NUMFIL
892*      1180 DO 1190 I = 1, MAXELM
893*      EE1 = EE1 + EFT(I, 2) * DELTA(I)
894*      1190 CONTINUE
895*      GOTO 1220
896*      1200 DO 1210 I = 1, MAXELM
897*      EE2 = EE2 + EFT(I, 3) * DELTA(I)
898*      EEFIG2 = EEFIG2 + EFT(I, 4) * DELTA(I)
899*      1210 CONTINUE
900*      GOTO 1180
901*      1220 CONTINUE

```

```

902* C CALCULATE THE EFFECTIVE ULTRAVIOLET IRRADIANCE ACCORDING TO ANY OF
903* C THE THREE ACTION SPECTRA(SLAMB,ULAMB,ALAMB) THROUGH EITHER FILTER
904* C OR BOTH FILTERS. THERE ARE NINE POSSIBLE QUANTITIES TO CALCULATE
905* C AND THE ONES TO BE CALCULATED ARE SPECIFIED ON INPUT BY FILCAL
906* C
907* DO 1320 I = 1,9
908* CAL = FILCAL(I)*1
909* GOTO(1320,1230,1240,1250,1260,1270,1280,1290,1300,1310),CAL
910* 1230 CALL FILSUB(FILTER,CAL,ELAMB,FT1,SLAMB,DELTA,$1320)
911* 1240 CALL FILSUB(FILTER,CAL,ELAMB,FT1,ULAMB,DELTA,$1320)
912* 1250 CALL FILSUB(FILTER,CAL,ELAMB,FT1,ALAMB,DELTA,$1320)
913* 1260 CALL FILSUB(FILTER,CAL,ELAMB,FT2,SLAMB,DELTA,$1320)
914* 1270 CALL FILSUB(FILTER,CAL,ELAMB,FT2,ULAMB,DELTA,$1320)
915* 1280 CALL FILSUB(FILTER,CAL,ELAMB,FT2,ALAMB,DELTA,$1320)
916* 1290 CALL FILSUM(FILTER,CAL,ELAMB,FT1,FT2,SLAMB,DELTA,$1320)
917* 1300 CALL FILSUM(FILTER,CAL,ELAMB,FT1,FT2,ULAMB,DELTA,$1320)
918* 1310 CALL FILSUM(FILTER,CAL,ELAMB,FT1,FT2,ALAMB,DELTA,$1320)
919* 1320 CONTINUE
920* 1330 CONTINUE
921* C
922* C *****
923* IDelta = IFIX(Delta(2))
924* WRITE(15,1331) EVENT,MAXELM,IDelta
925* 1331 FORMAT(3A6,I4,I2)
926* DO 1333 I = 1,MAXELM
927* WRITE(15,1332) ELAMB(I,1)
928* 1332 FORMAT(F5.0)
929* 1333 CONTINUE
930* DO 1335 I = 1,MAXELM
931* WRITE(15,1334) ELAMB(I,2)
932* 1334 FORMAT(E9.4)
933* 1335 CONTINUE
934* C *****
935* C
936* C
937* C PRINT THE TABLE DATA---MUST DETERMINE IF THERE IS FILTER DATA AND
938* C IF THERE IS A GENERAL WEIGHTING DATA TO BE PRINTED AND IF FILTER
939* C DATA IS TO BE PRINTED WHETHER IT IS ONE OR TWO FILTERS
940* C
941* CALL DATEIM(DATE)
942* PEAK = 0
943* PAGE = 0
944* LYNE=58
945* LINMAX = 57
946* K = 1
947* IF(GENWEI .GT. 0) K = 2
948* K = K + NUMFIL * 2
949* GOTO(1340,1370,1400,1430,1460,1490),K
950* C
951* C PRINT TABLE WITH NO GENERAL WEIGHTING AND NO FILTER DATA
952* C
953* 1340 K = 1
954* DO 1360 I = 1,MAXELM
955* CALL PRCON
956* CFRES = SEQUEN(EINSTR,I,CF,K)
957* PRINT 1350,EINSTR(I,1),CFRES,EINSTR(I,2),E F OF X(I,2),ELAMB(I,2),
958* 1 LLAMB(I,2),ERETLB(I,2),ERETLB(I,3)

```

```

959*      1350 FORMAT('D',T2,F5.0,T8,7(1PE9.4,2X))
960*      1360 CONTINUE
961*      GOTO 1515
962*      C
963*      C      PRINT TABLE WITH GENERAL WEIGHTING DATA, NO FILTER DATA
964*      C
965*      1370 K = 1
966*      DO 1390 I = 1,MAXELM
967*      CALL PRICON
968*      CFRES = SEQUEN(EINSTR,I,CF,K)
969*      PRINT 1380,EINSTR(I,1),CFRES,EINSTR(I,2),E1F OFX(I,2),ELAMBD(I,2),
970*      1 LLAMBD(I,2),(ERETLB(I,J),J=2,3),GLAMBD(I,2)
971*      1380 FORMAT('D',F5.0,T8,8(1PE9.4,2X))
972*      1390 CONTINUE
973*      GOTO 1515
974*      C
975*      C      PRINT TABLE WITH ONE FILTER AND NO GENERAL WEIGHTING DATA
976*      C
977*      1400 K = 1
978*      DO 1420 I = 1,MAXELM
979*      CALL PRICON
980*      CFRES = SEQUEN(EINSTR,I,CF,K)
981*      PRINT 1410,EINSTR(I,1),CFRES,EINSTR(I,2),E1F OFX(I,2),ELAMBD(I,2),
982*      1 LLAMBD(I,2),(ERETLB(I,J),J=2,3),EFT(I,2)
983*      1410 FORMAT('D',F5.0,T8,7(1PE9.4,2X),T96,1PE9.4)
984*      1420 CONTINUE
985*      GOTO 1515
986*      C
987*      C      PRINT TABLE WITH GENERAL WEIGHTING AND ONE FILTER
988*      C
989*      1430 K = 1
990*      DO 1450 I = 1,MAXELM
991*      CALL PRICON
992*      CFRES = SEQUEN(EINSTR,I,CF,K)
993*      PRINT 1440,EINSTR(I,1),CFRES,EINSTR(I,2),E1F OFX(I,2),ELAMBD(I,2),
994*      1 LLAMBD(I,2),(ERETLB(I,J),J=2,3),GLAMBD(I,2),EFT(I,2)
995*      1440 FORMAT('D',F5.0,T8,9(1PE9.4,2X))
996*      1450 CONTINUE
997*      GOTO 1515
998*      C
999*      C      PRINT TABLE WITH TWO FILTERS AND NO GENERAL WEIGHTING DATA
1000*      C
1001*      1460 K = 1
1002*      DO 1480 I = 1,MAXELM
1003*      CALL PRICON
1004*      CFRES = SEQUEN(EINSTR,I,CF,K)
1005*      PRINT 1470,EINSTR(I,1),CFRES,EINSTR(I,2),E1F OFX(I,2),ELAMBD(I,2),
1006*      1 LLAMBD(I,2),(ERETLB(I,J),J=2,3),(EFT(I,L),L=2,4)
1007*      1470 FORMAT('D',F5.0,T8,7(1PE9.4,2X),T96,3(E9.4,2X))
1008*      1480 CONTINUE
1009*      GOTO 1515
1010*      C
1011*      C      PRINT TABLE WITH GENERAL WEIGHTING AND BOTH FILTERS
1012*      C
1013*      1490 K = 1
1014*      DO 1510 I = 1,MAXELM
1015*      CALL PRICON

```

```

1016*      CFRES = SEQUEN(EINSTR,I,CF,K)
1017*      PRINT 1500,EINSTR(I,1),CFRES,EINSTR(I,2),EIFOFX(I,2),ELAMBD(I,2),
1018*      1 LLAMBD(I,2),(ERETLB(I,J),J=2,3),ELAMBD(I,2),(LEFT(I,L),L=2,4)
1019*      1500 FORMAT('0',F5.0,T8,11(1PE9.4,2X))
1020*      1510 CONTINUE
1021*      1515 PRINT 1520
1022*      1520 FORMAT('1')
1023*      PAGE=PAGE+1
1024*      PRINT 6010,DATE,PAGE
1025*      PRINT 6020,DESCRP
1026*      PRINT 6025,EVENT,OMEGA
1027*      6025 FORMAT(T2,'SOURCE DESCRIPTION: ',
1028*      A 3A6,'. SOLID ANGLE = ',E9.2)
1029*      IF (ITEST.EQ. 0) GOTO 6130
1030*      GOTO (6131,6132,6133),ITEST
1031*      6130 PRINT 6030
1032*      GOTO 6040
1033*      6131 PRINT 6031
1034*      GOTO 6040
1035*      6132 PRINT 6032
1036*      GOTO 6040
1037*      6133 PRINT 6033
1038*      6010 FORMAT(T2,'LMD SPECTRAL WEIGHTING PROGRAM',T90,'DATE ',2A6,
1039*      1 T110,'PAGE ',I3)
1040*      C
1041*      6020 FORMAT('0',T2,13A6,A2/T2,13A6,A2)
1042*      C
1043*      6030 FORMAT(//T45,'SUMMARIZATION SHEET FOR SOURCE ',
1044*      A /,T2,120(' '-'))
1045*      6031 FORMAT(//T37,'SUMMARIZATION SHEET FOR SOURCE
1046*      A WITH FILTER ONE',/,T2,120(' '-'))
1047*      6032 FORMAT(//T37,'SUMMARIZATION SHEET FOR SOURCE
1048*      A WITH FILTER TWO',/,T2,120(' '-'))
1049*      6033 FORMAT(//T30,'SUMMARIZATION SHEET FOR SOURCE
1050*      A WITH FILTERS ONE AND TWO',/,T2,120(' '-'))
1051*      6040 PRINT 1650,EDLLB
1052*      PRINT 1655,LDLLB
1053*      PRINT 1660,ACGIH
1054*      PRINT 1670,CIE
1055*      PRINT 1680,ANSI
1056*      PRINT 1690,BLUHAZ
1057*      PRINT 1700,XBAR
1058*      PRINT 1710,YBAR
1059*      PRINT 1720,ZBAR
1060*      PRINT 1730,P445
1061*      PRINT 1740,P535
1062*      PRINT 1750,P575
1063*      PRINT 1760,VE
1064*      PRINT 1770,VIE
1065*      PRINT 1780,TRANS
1066*      PRINT 1790,TRANIX
1067*      PRINT 1800,EECA
1068*      PRINT 1810,PCTUV
1069*      PRINT 1820,PCTVI
1070*      PRINT 1830,PCTNIR
1071*      C
1072*      C PRINT FILTER DATA IF PRESENT

```



```

1073*      C
1074*      IF (NUMFIL .EQ. 0) GOTO 1645
1075*      PRINT 1840,EEF1
1076*      GOTO(1540,1530),NUMFIL
1077*      1530 PRINT 1850,EEF2
1078*      PRINT 1860,EEF1G2
1079*      1540 DO 1640 I = 1,3
1080*          IF (FILCAL(I) .EQ. 0) GOTO 1645
1081*          M = FILCAL(I)
1082*          GOTO(1550,1560,1570,1580,1590,1600,1610,1620,1630),M
1083*      1550 PRINT 1870,LAMBDA(1),FLTCNT(1),FILTER(1)
1084*          GOTO 1640
1085*      1560 PRINT 1870,LAMBDA(2),FLTCNT(1),FILTER(2)
1086*          GOTO 1640
1087*      1570 PRINT 1870,LAMBDA(3),FLTCNT(1),FILTER(3)
1088*          GOTO 1640
1089*      1580 PRINT 1870,LAMBDA(1),FLTCNT(2),FILTER(4)
1090*          GOTO 1640
1091*      1590 PRINT 1870,LAMBDA(2),FLTCNT(2),FILTER(5)
1092*          GOTO 1640
1093*      1600 PRINT 1870,LAMBDA(3),FLTCNT(2),FILTER(6)
1094*          GOTO 1640
1095*      1610 PRINT 1870,LAMBDA(1),FLTCNT(3),FILTER(7)
1096*          GOTO 1640
1097*      1620 PRINT 1870,LAMBDA(2),FLTCNT(3),FILTER(8)
1098*          GOTO 1640
1099*      1630 PRINT 1870,LAMBDA(3),FLTCNT(3),FILTER(9)
1100*      1640 CONTINUE
1101*      1645 PRINT 1880,ILLUM
1102*          PRINT 1890,LUMIN
1103*          IF (NUMFIL .EQ. 0) GOTO 1646
1104*          IF (ITEST .EQ. 0) GOTO 1041
1105*          GOTO (1042,1043),ITEST
1106*      1646 CALL INITIL
1107*          GOTO 530
1108*      1650 FORMAT('D TOTAL SPECTRAL IRRADIANCE FOR THE WAVELENGTH LIMITS USED
1109*          1 FOR THE INSTRUMENT READINGS',T100,1PE9.4)
1110*      1655 FORMAT('D TOTAL RADIANCE OF SOURCE FROM LAMBDA-MIN TO LAMBDA-MAX'
1111*          1 ,T100,1PE9.4)
1112*      1660 FORMAT('D EFFECTIVE ULTRAVIOLET IRRADIANCE ACCORDING TO THE ACGIH
1113*          1 STANDARD ACTION SPECTRUM',T100,1PE9.4)
1114*      1670 FORMAT('D EFFECTIVE ULTRAVIOLET IRRADIANCE ACCORDING TO 1936 CIE U
1115*          1 LTRAVIOLET ERYTHEMA ACTION SPECTRUM',T100,1PE9.4)
1116*      1680 FORMAT('D EFFECTIVE ULTRAVIOLET IRRADIANCE ACCORDING TO ANSI-Z136
1117*          1 LASER WEIGHTING UV HAZARD FUNCTION',T100,1PE9.4)
1118*      1690 FORMAT('D BLUE LIGHT HAZARD FUNCTION WEIGHTED AGAINST SPECTRAL IRR
1119*          1 ADIANCE',T100,1PE9.4)
1120*      1700 FORMAT('D 1931 BLUE CHROMATICITY COORDINATES WEIGHTED AGAINST SPEC
1121*          1 TRAL IRRADIANCE',T100,1PE9.4)
1122*      1710 FORMAT('D 1931 GREEN CHROMATICITY COORDINATES WEIGHTED AGAINST SPE
1123*          1 CTRAL IRRADIANCE',T100,1PE9.4)
1124*      1720 FORMAT('D 1931 RED CHROMATICITY COORDINATES WEIGHTED AGAINST SPECT
1125*          1 RAL IRRADIANCE',T100,1PE9.4)
1126*      1730 FORMAT('D DARTNALL NOMOGRAM ABSORPTION COEFFICIENT FOR BLUE WEIGH
1127*          1 TED AGAINST SPECTRAL IRRADIANCE',T100,1PE9.4)
1128*      1740 FORMAT('D DARTNALL NOMOGRAM ABSORPTION COEFFICIENT FOR GREEN WEIGH
1129*          1 TED AGAINST SPECTRAL IRRADIANCE',T100,1PE9.4)

```

```

1130* 1750 FORMAT('D DARTNALL NOMOGRAM ABSORPTION COEFFICIENT FOR RED WEIGH
1131*      1TED AGAINST SPECTRAL IRRADIANCE',T100,1PE9.4)
1132* 1760 FORMAT('D RADIANT EFFICACY (LUMENS/WATT) OF RADIATION FROM LAMBDA-
1133*      1MIN TO LAMBDA-MAX',T100,1PE9.4)
1134* 1770 FORMAT('D FACTION CIE SCOTOPIC RADIATION FROM LAMBDA-MIN TO LAMBDA
1135*      1-MAX',T100,1PE9.4)
1136* 1780 FORMAT('D EFFECTIVE TRANSMISSION OF OCULAR MEDIA FROM LAMBDA-MIN T
1137*      1O LAMBDA-MAX',T100,1PE9.4)
1138* 1790 FORMAT('D EFFECTIVE TRANSMISSION OF OCULAR MEDIA MULTIPLIED BY SPE
1139*      1CTRAL ABSORPTION OF OCULAR MEDIA',T100,1PE9.4)
1140* 1800 FORMAT('D ANSI LASER MPE WEIGHTING FACTOR FOR VISIBLE AND INFRARED
1141*      1-A',T100,1PE9.4)
1142* 1810 FORMAT('D PERCENT OF TOTAL IRRADIANCE BETWEEN LAMBDA-MIN AND LAMBDA
1143*      1A-MAX WHICH IS ULTRAVIOLET RADIATION',T100,1PE9.4)
1144* 1820 FORMAT('D PERCENT OF TOTAL IRRADIANCE BETWEEN LAMBDA-MIN AND LAMBDA
1145*      1A-MAX WHICH IS VISIBLE RADIATION',T100,1PE9.4)
1146* 1830 FORMAT('D PERCENT OF TOTAL IRRADIANCE BETWEEN LAMBDA-MIN AND LAMBDA
1147*      1A-MAX WHICH IS NEAR INFRARED RADIATION',T100,1PE9.4)
1148* 1840 FORMAT('D TOTAL SPECTRAL IRRADIANCE WEIGHTED SPECTRALLY AGAINST TH
1149*      1E TRANSMISSION OF FILTER ONE',T100,1PE9.4)
1150* 1850 FORMAT('D TOTAL SPECTRAL IRRADIANCE WEIGHTED SPECTRALLY AGAINST TH
1151*      1E TRANSMISSION OF FILTER TWO',T100,1PE9.4)
1152* 1860 FORMAT('D TOTAL SPECTRAL IRRADIANCE WEIGHTED SPECTRALLY AGAINST TH
1153*      1E TRANSMISSION OF BOTH FILTERS',T100,1PE9.4)
1154* 1870 FORMAT('D EFFECTIVE UV IRRADIANCE ACCORDING TO '.2A4, ' ACTION SPE
1155*      1CTRA THROUGH ', A6,T100,1PE9.4)
1156* 1880 FORMAT('D ILLUMINANCE IN LUMENS PER SQUARE CENTIMETER',T100,1PE9.4
1157*      1)
1158* 1890 FORMAT('D LUMINANCE IN CANDELAS PER SQUARE CENTIMETER',T100,1PE9.4
1159*      1)
1160* 9999 END FILE 15
1161*      REWIND 15
1162*      CALL HPLLOT
1163*      PRINT 1900
1164* 1900 FORMAT('1', ' ALL PROCESSING COMPLETED')
1165*      STOP
1166* C
1167* C
1168* C *****
1169* C * END OF MAIN PROGRAM *
1170* C * SUBROUTINES FOLLOW *
1171* C *
1172* C *****
1173* C
1174* C
1175* C *****
1176* C * SUBROUTINE IDENT *
1177* C *
1178* C *****
1179* C
1180* C
1181* C
1182* C PRINT OUT THE INPUT PARAMETERS CONVERTING TO
1183* C NARRATIVE WHEN POSSIBLE
1184* C
1185* C
1186* C

```

```

1187* SUBROUTINE IDENT
1188* DIMENSION FILTAB(10,7),CALTAB(2,3),GFTAB(16,4)
1189* INTEGER FILTAB
1190* INTEGER CALTAB
1191* INTEGER GFTAB
1192* DATA ((FILTAB(I,J),J=1,7),I=1,10)/
1193* A*NO FIL*,*TER CA*,*LCULAT*,*ION * * * *
1194* 1*E-LAMB*,*DA*FIL*,*TER1*S*,*LAMBDA*,*DELTA* * * *
1195* 2*E-LAMB*,*DA*FIL*,*TER1*U*,*LAMBDA*,*DELTA* * * *
1196* 3*E-LAMB*,*DA*FIL*,*TER1*A*,*LAMBDA*,*DELTA* * * *
1197* 4*E-LAMB*,*DA*FIL*,*TER2*S*,*LAMBDA*,*DELTA* * * *
1198* 5*E-LAMB*,*DA*FIL*,*TER2*U*,*LAMBDA*,*DELTA* * * *
1199* 6*E-LAMB*,*DA*FIL*,*TER2*F*,*LAMBDA*,*DELTA* * * *
1200* 7*E-LAMB*,*DA*FIL*,*TER1*F*,*ILTER2*,*J-LAB*,*BDA*DE*,*LTA *
1201* 8*E-LAMB*,*DA*FIL*,*TER1*F*,*ILTER2*,*U-LAB*,*BDA*DE*,*LTA *
1202* 9*E-LAMB*,*DA*FIL*,*TER1*F*,*ILTER2*,*F-LAB*,*BDA*DE*,*LTA */
1203* DATA ((CALTAB(IC,JC),JC=1,3),IC=1,2) /
1204* 1*RAW DA*,*TA * *
1205* 2*CALCUL*,*ATED D*,*ATA */
1206* DATA ((GFTAB(IG,JG),JG=1,4),IG=1,16) /
1207* 1*WEIGHT*,*ING FN*,* IN PR*,*OGRAM *
1208* 2*ELAMBD*,*A*S-LA*,*MBDA * *
1209* 3*ELAMBD*,*A*U-LA*,*MBDA * *
1210* 4*ELAMBD*,*A*A-LA*,*MBDA * *
1211* 5*ELAMBD*,*A*T-LA*,*MBDA * *
1212* 6*ELAMBD*,*A*TA-L*,*MBDA * *
1213* 7*ELAMBD*,*A*CA-L*,*MBDA * *
1214* 8*ELAMBD*,*A*U-LA*,*MBDA * *
1215* 9*ELAMBD*,*A*VP-L*,*MBDA * *
1216* A*ELAMBD*,*A*D-LA*,*MBDA * *
1217* 9*ELAMBD*,*A*XBAR*,*LAMBDA*,*A *
1218* C*ELAMBD*,*A*YBAR*,*LAMBDA*,*A *
1219* D*ELAMBD*,*A*ZBAR*,*LAMBDA*,*A *
1220* E*ELAMBD*,*A*P445*,*LAMBDA*,*A *
1221* F*ELAMBD*,*A*P535*,*LAMBDA*,*A *
1222* G*ELAMBD*,*A*P575*,*LAMBDA*,*A */
1223* 6000 FORMAT(1H1,T5,* DESCRIPTION : *,13A6,A2/,T10,13A6,A2,/)
1224* 6010 FORMAT(T20,*NCCOF1 = *,I2,* CALCULATED
1225* A DATA USED FOR FILTER ONE*/)
1226* 6011 FORMAT(T20,*NCCOF1 = *,I2,* RAW DATA USED FOR FILTER ONE*/)
1227* 6012 FORMAT(T20,*NCCOF2 = *,I2,* CALCULATED
1228* A DATA USED FOR FILTER TWO*/)
1229* 6013 FORMAT(T20,*NCCOF2 = *,I2,* RAW DATA USED FOR FILTER TWO*/)
1230* 6001 FORMAT(T20,*NUMBER OF FILTERS USED = *,I2,/)
1231* 6020 FORMAT(T20,*CALDAT = *,I2,* CALIBRATION INPUT IS RAW DATA*/)
1232* 6021 FORMAT(T20,*CALDAT = *,I2,* CALIBRATION INPUT IS CALCULATED DATA
1233* A*/)
1234* 6022 FORMAT(T20,*CALDAT = *,I2,* NO CALIBRATION INPUT, TABLE SET TO *,
1235* A *ONES*/)
1236* 6030 FORMAT(T20,*GENFUN = *,I2,* GENERAL FUNCTION IS IN COMPUTER*
1237* A * PROGRAM*/)
1238* 6031 FORMAT(T20,*GENFUN = *,I2,* READ INTO COMPUTER THE GENERAL FUNCTI
1239* A ON DATA*/)
1240* 6040 FORMAT(T20,7A6)
1241* 6050 FORMAT(T20,4A6)
1242* 6060 FORMAT (T20,*ULTRAVIOLET DISTANCE = *,F9.2/,
1243* A T20,*VISIBLE LIGHT DISTANCE = *,F9.2)

```

```

1244* C
1245* C
1246* C
1247* C PRINT DESCRIPTION
1248* PRINT 6000,(DESCRP(I),I=1,28)
1249* C PRINT NUMBER OF FILTERS USED
1250* PRINT 6001,NUMFIL
1251* C PRINT CALCULATED/RAW FILTER DATA
1252* IF (NOCOF1 .EQ. 1) GO TO 10
1253* PRINT 6011,NOCOF1
1254* GO TO 20
1255* 10 CONTINUE
1256* PRINT 6010,NOCOF1
1257* 20 IF (NUMFIL .EQ. 1) GOTO 25
1258* IF (NOCOF2 .EQ. 1) GOTO 11
1259* PRINT 6013,NOCOF2
1260* GOTO 25
1261* 11 PRINT 6012,NOCOF2
1262* C PRINT FILTER CALIBRATION FROM FILTAB
1263* 25 IX=FILCAL+1
1264* PRINT 6040, (FILTAB(IX,IY),IY=1,7)
1265* C PRINT DATA TYPE
1266* ICAL=CALDAT+1
1267* GO TO (30,31,33),ICAL
1268* 31 CONTINUE
1269* PRINT 6021,CALDAT
1270* PRINT 6023,CALHDR
1271* 6023 FORMAT(I20,'CALIBRATION : ',13A6,A2)
1272* GO TO 40
1273* 30 CONTINUE
1274* PRINT 6020,CALDAT
1275* PRINT 6023,CALHDR
1276* GO TO 40
1277* 33 CONTINUE
1278* PRINT 6022,CALDAT
1279* 40 CONTINUE
1280* C PRINT GENERAL WEIGHTING TABLE
1281* IX=GENWEI+1
1282* PRINT 6050,(GFTAB(IX,IY),IY=1,4)
1283* C PRINT GENERAL FUNCTION
1284* IF (GENFUN .EQ. 0) GO TO 50
1285* PRINT 6031,GENFUN
1286* PRINT 6069,FWAVE,LWAVE
1287* PRINT 6070,DATA
1288* GO TO 60
1289* 50 CONTINUE
1290* PRINT 6030,GENFUN
1291* 60 CONTINUE
1292* C
1293* PRINT 6060,DFU,DFV
1294* 6069 FORMAT(I20,'FOR WAVELENGTHS ',I4,' TO ',I4)
1295* 6070 FORMAT(I20,'GENERAL FUNCTION VALUE IS ',E9.2)
1296* RETURN
1297* C
1298* C
1299* C
1300* C

```

\*\*\*\*\*  
 \* SUBROUTINE INITL \*



```

1301*      C      * ..... *
1302*      C      * ..... *
1303*      C
1304*      C      SUBROUTINE INITIL
1305*      C
1306*      C      THIS SUBROUTINE INITIALIZES MAIN PROGRAM VARIABLES
1307*      C
1308*      C      DO 20 I = 1,2
1309*      C          DO 10 J = 1,340
1310*      C              EINST(I,J,I) = 0
1311*      C              EIFOX(I,J,I) = 0
1312*      C              ELAMBD(I,J,I) = 0
1313*      C              LLAMBD(I,J,I) = 0
1314*      C              ERETLB(I,J,I) = 0
1315*      C              GLAMBD(I,J,I) = 0
1316*      C      10 CONTINUE
1317*      C      20 CONTINUE
1318*      C          DO 40 I = 1,4
1319*      C              DO 30 J = 1,340
1320*      C                  EFT(I,J,I) = 0
1321*      C      30 CONTINUE
1322*      C      40 CONTINUE
1323*      C          DO 50 I = 1,340
1324*      C              ERETLB(I,3) = 0
1325*      C              DELTA(I) = 0
1326*      C      50 CONTINUE
1327*      C          DO 60 I = 1,9
1328*      C              FILTER(I) = 0
1329*      C      60 CONTINUE
1330*      C      RETURN
1331*      C
1332*      C      * ..... *
1333*      C      * SUBROUTINE INTERP *
1334*      C      * ..... *
1335*      C
1336*      C
1337*      C
1338*      C      SUBROUTINE INTERP(X,Y,I,J,Z)
1339*      C
1340*      C      THIS SUBROUTINE INTEPOLES THE DATA IN ARRAY Y TO CORRESPOND TO ARRAY
1341*      C      X AND PUTS THE RESULT IN Z
1342*      C
1343*      C      REAL X(340,2)
1344*      C      REAL Y(340,2)
1345*      C      A = Y(J,1) - Y(J-1,1)
1346*      C      B = Y(J,2) - Y(J-1,2)
1347*      C      C = B / A
1348*      C      D = X(I,1) - Y(J-1,1)
1349*      C      E = D * C
1350*      C      Z = Y(J-1,2) + E
1351*      C      RETURN
1352*      C
1353*      C      * ..... *
1354*      C      * FUNCTION SUM *
1355*      C      * ..... *
1356*      C
1357*      C

```

```

1358* C
1359* REAL FUNCTION SUM(E,X,D)
1360* C
1361* C THIS FUNCTION SUMS THE PRODUCTS OF EACH ELEMENT OF E,X,D ARRAYS
1362* C
1363* DIMENSION E(340,2),
1364* 1 X(340,2),
1365* 2 D(340)
1366* K = 1
1367* SUM = 0
1368* DO 50 I = 1,MAXELM
1369* IF(E(I,1) .LT. 0) GOTO 50
1370* IF(E(I,1) .LT. X(1,1)) GOTO 50
1371* 10 IF(E(I,1) .EQ. X(K,1)) GOTO 30
1372* IF(E(I,1) .LT. X(K,1)) GOTO 20
1373* K = K + 1
1374* GOTO 10
1375* 20 CALL INTERP(E,X,I,K,R)
1376* GOTO 40
1377* 30 R = X(K,2)
1378* 40 SUM = SUM + E(I,2) * R * D(I)
1379* 50 CONTINUE
1380* K = 1
1381* DO 80 I = 1,MAXELM
1382* IF(E(I,1) .GE. 0) GOTO 80
1383* DO 60 J = K,MAXELM
1384* IF(E(I,1) .LT. X(J,1)) GOTO 70
1385* 60 CONTINUE
1386* 70 K = J
1387* R = X(K,2)
1388* IF(E(I,1) .NE. X(K,1)) CALL INTERP(E,X,I,K,R)
1389* CONT = E(I,2) - E(I-1,2)
1390* IF((E(I,1) - E(I-1,1)) .EQ. (E(I+1,1) - E(I,1))) CONT = (E(I+1,2)
1391* 1 + E(I-1,2)) / 2
1392* SUM = SUM + CONT * R * D(I-1)
1393* PK = E(I,2) - CONT
1394* SUM = SUM + PK * R * D(I)
1395* 80 CONTINUE
1396* RETURN
1397* C
1398* C
1399* C
1400* C
1401* C
1402* C
1403* C
1404* REAL FUNCTION SUM1(E,D,L,H)
1405* C
1406* C THIS FUNCTION SUMS THE PRODUCTS OF EACH ELEMENT OF E,D ARRAYS
1407* C
1408* DIMENSION E(340,2),
1409* 1 D(340)
1410* INTEGER L,H
1411* SUM1 = 0
1412* DO 10 I = L,H
1413* IF(E(I,1) .LT. 0) GOTO 10
1414* SUM1 = SUM1 + E(I,2) * D(I)

```

```

1415*      10 CONTINUE
1416*      DO 20 I = L,H
1417*      IF(E(I,1) .GT. 0) GOTO 20
1418*      CONT = E(I,2) - E(I-1,2)
1419*      IF((E(I,1) - E(I-1,1)) .EQ. (E(I+1,1) - E(I,1))) CONT = (E(I+1,2)
1420*      1 + E(I-1,2)) / 2
1421*      SUM1 = SUM1 + CONT * D(I-1)
1422*      PK = E(I,2) - CONT
1423*      SUM1 = SUM1 + PK * D(I)
1424*      20 CONTINUE
1425*      RETURN
1426*
1427*
1428*
1429*
1430*
1431*
1432*
1433*      SUBROUTINE GLAMCO(R,X,Y,S)
1434*
1435*      SUBROUTINE MULTIPLIES EACH ELEMENT IN X WITH ITS CORRESPONDING
1436*      ELEMENT IN Y PUTTING IT IN ARRAY R
1437*
1438*      DIMENSION R(340,2),
1439*      1          X(340,2),
1440*      1          Y(340,2)
1441*      K = 1
1442*      DO 50 I = 1,MAXELM
1443*      10 IF(X(I,1) .EQ. Y(K,1)) GOTO 30
1444*      IF(X(I,1) .LT. Y(K,1)) GOTO 20
1445*      K = K + 1
1446*      GOTO 10
1447*      20 CALL INTERP(X,Y,I,K,Z)
1448*      GOTO 40
1449*      30 Z = Y(K,2)
1450*      40 R(I,1) = X(I,1)
1451*      R(I,2) = X(I,2) * Z
1452*      50 CONTINUE
1453*      J=4
1454*      RETURN J
1455*
1456*
1457*
1458*
1459*
1460*
1461*
1462*      SUBROUTINE FILSUM(R,N,X,Y,Y1,Z,D,S)
1463*
1464*      THIS SUBROUTINE SUMS THE PRODUCTS OF EACH ELEMENT OF X,Y,Y1,Z,D ARRAYS
1465*
1466*
1467*      DIMENSION R(340,2),
1468*      1          X(340,2),
1469*      2          Y(340,2),
1470*      3          Y1(340,2),
1471*      4          Z(340,2),

```

```

1472*      5      D(340).
1473*      7      RLS(340,2).
1474*      6      Y(340,2)
1475*      DO 10 I = 1,340
1476*      IF(Y(I,1) .EQ. 0) GOTO 20
1477*      T(I,1) = Y(I,1)
1478*      T(I,2) = Y(I,2) * Y1(I,2)
1479*  10 CONTINUE
1480*  20 L = 8
1481*      GOTO 30
1482*      ENTRY FILSUB(R,N,X,T,Z,D,S)
1483*      L = 7
1484*  30 N = N - 1
1485*      R(N) = 0
1486*      J = 1
1487*      K = 1
1488*      DO 110 I = 1,MAXELM
1489*  40 IF(ABS(X(I,1)) .EQ. T(K,1)) GOTO 60
1490*      IF(ABS(X(I,1)) .LT. T(K,1)) GOTO 50
1491*      K = K + 1
1492*      GOTO 40
1493*  50 CALL INTERP(X,T,I,K,A)
1494*      GOTO 70
1495*  60 A = T(K,2)
1496*  70 IF(ABS(X(I,1)) .EQ. Z(J,1)) GOTO 90
1497*      IF(ABS(X(I,1)) .LT. Z(J,1)) GOTO 80
1498*      J = J + 1
1499*      GOTO 70
1500*  80 CALL INTERP(X,Z,I,J,B)
1501*      GOTO 100
1502*  90 B = Z(J,2)
1503* 100 RLS(I,1) = ABS(X(I,1))
1504*      RLS(I,2) = A * B
1505* 110 CONTINUE
1506*      R(N) = SUM(X,RLS,D)
1507*      RETURN L
1508*  C
1509*  C
1510*  C
1511*  C
1512*  C
1513*  C
1514*  C
1515*      REAL FUNCTION SEQUEN(X,I,Y,J)
1516*  C
1517*  C      THIS FUNCTION RETURNS THE VALUE IN Y(I,2) FOR WHICH Y(I,1) MATCHES X(I,1)
1518*  C
1519*      DIMENSION X(340,2),
1520*      1      Y(340,2)
1521*  10 IF(X(I,1) .EQ. Y(J,1)) GOTO 20
1522*      IF(X(I,1) .LT. Y(J,1)) GOTO 30
1523*      J = J + 1
1524*      GOTO 10
1525*  20 SEQUEN = Y(J,2)
1526*      GOTO 40
1527*  30 CALL INTERP(X,Y,I,J,SEQUEN)
1528*  40 RETURN

```



```

1529* C
1530* C
1531* C
1532* C
1533* C
1534* C
1535* C
1536* SUBROUTINE PRYCON
1537* C
1538* C CONTROL THE PRINTING OF THE LISTING
1539* C
1540* LYNE = LYNE + 2
1541* IF(PEAK .EQ. 0) GOTO 20
1542* PRINT 10
1543* 10 FORMAT('0',34(' ')/)
1544* LYNE = LYNE + 4
1545* PEAK = 0
1546* 20 IF(LYNE .LT. LINMAX) GOTO 30
1547* PAGE = PAGE + 1
1548* CALL HEADIN
1549* LYNE = 12
1550* 30 IF(EINSTR(I,1) .GT. 0) GOTO 60
1551* IF((LYNE + 6) .LT. LINMAX) GOTO 40
1552* PAGE = PAGE + 1
1553* CALL HEADIN
1554* 40 PRINT 50
1555* 50 FORMAT('0'//10(' '),5(' '),*PEAK',5(' '),1(' '))
1556* LYNE = LYNE + 4
1557* EINSTR(I,1) = ABS(EINSTR(I,1))
1558* PEAK = 1
1559* 60 RETURN
1560* C
1561* C
1562* C
1563* C
1564* C
1565* C
1566* C
1567* SUBROUTINE HEADIN
1568* C
1569* C PRINTS THE PAGE HEADING
1570* C
1571* PRINT 10,DATE,PAGE
1572* PRINT 20,DESCRP
1573* PRINT 30,EVENT
1574* PRINT 35,OMEGA
1575* 35 FORMAT(' SOURCE SOLID ANGLE IS 'E9.2)
1576* PRINT 40
1577* PRINT 50
1578* PRINT 60,(PRTLAM(GENWEI+1,I),I=1,3)
1579* PRINT 70
1580* 10 FORMAT('1',T2,*LMD SPECTRAL WEIGHTING PROGRAM',T90,*DATE ',2A6,
1581* 1T110,*PAGE ',I3)
1582* 20 FORMAT('0',T2,13A6,A2/T2,13A6,A2)
1583* 30 FORMAT(' ',T2,3A6)
1584* 40 FORMAT('0',T31, 'ADJUSTED SPECTRAL SPECTRAL SPECTRAL-RETIN
1585* 1AL GENERAL SPECTRAL FILTER TRANSMISSIONS')

```

```

1586*      50 FORMAT(' ',T3,'WAVE  CALIBRAT  INSTRUMENT INSTRUMENT IRRADIANCE
1587*      1RADIANCE      IRRADIANCE      WEIGHTING      FILTER      FILTER
1588*      2  FILTER')
1589*      60 FORMAT(' ',T2,'LENGTH  FACTOR  READINGS  READINGS  SOURCE
1590*      1  SOURCE      (3-MM)      (7-MM)  ',2A6,A2,T10,'ONE      TWO      0
1591*      2NE  * TWO')
1592*      70 FORMAT(' ',T2,'-----',11(2X,9(' ')))
1593*      RETURN
1594*
1595*      C
1596*      C
1597*      C
1598*      C
1599*      C
1600*      C
1601*      SUBROUTINE BDREAD(TABLE)
1602*
1603*      C
1604*      C
1605*      C
1606*      DIMENSION TABLE(340,2)
1607*      DO 20 I = 1,340
1608*      READ(5,10,ERR=30)(TABLE(I,J),J=1,2)
1609*      10 FORMAT(F4.0,T9,E9.2)
1610*      20 CONTINUE
1611*      GOTO 50
1612*      30 READ(0,40) M
1613*      40 FORMAT(A3)
1614*      IF(M.EQ. 'END') GOTO 70
1615*      50 PRINT 60
1616*      60 FORMAT('0 BIODECK DID NOT END CORRECTLY')
1617*      STOP
1618*      70 RETURN
1619*
1620*      C
1621*      C
1622*      C
1623*      C
1624*      C
1625*      SUBROUTINE HPLOT
1626*
1627*      C
1628*      C
1629*      C
1630*      DIMENSION XAXIS(685),YAXIS(685),IBUF(5000)
1631*      INTEGER EVENT(3)
1632*      CALL PLOTS(IBUF,5000,20)
1633*      CALL PLOT(0.,-36.,-3)
1634*      CALL PLOT(0.,2.,-3)
1635*      CALL SYMBOL(0.,0.,0.21,17HAEHA,X24 75,LMDSWP,90.,17)
1636*      CALL PLOT(2.,-0.8,-3)
1637*      NPLT = 0
1638*      4 READ(15,10,END=999) EVENT,ISIZE,INCREM,FIG,CM
1639*      10 FORMAT(3A6,I4,I2,A2,A5)
1640*      EVENT2(10)=EVENT(1)
1641*      EVENT2(11)=EVENT(2)
1642*      EVENT2(12)=EVENT(3)
1643*      READ(15,20) XAXIS(1)

```

```

1643*      20 FORMAT(F5.0)
1644*      L=2
1645*      K=3
1646*      IDelta = INCREM/2
1647*      DO 30 I=2,ISIZE
1648*      READ(15,20) XAXIS(L)
1649*      XAXIS(L)=XAXIS(L)-IDelta
1650*      XAXIS(K)=XAXIS(L)
1651*      L = L + 2
1652*      K = K + 2
1653*      30 CONTINUE
1654*      XAXIS(L) = XAXIS(K-2) + INCREM
1655*      ISIZE = ISIZE*2
1656*      DO 50 I = 1,ISIZE,2
1657*      READ(15,40) YAXIS(I)
1658*      40 FORMAT(E9.4)
1659*      YAXIS(I+1)=YAXIS(I)
1660*      50 CONTINUE
1661*      IF (NPLT .EQ. 0) GOTO 5
1662*      63 IF (MOD(NPLT,4) .EQ. 0) GOTO 60
1663*      CALL PLOT(-0.79,7.1,-3)
1664*      GOTO 5
1665*      60 CALL PLOT(10.15,-36,-3)
1666*      CALL PLOT(3.,1.2,-3)
1667*      5 NPLT = NPLT + 1
1668*      C DRAW BORDER, HAVING ESTABLISHED LOWER LEFT CORNER
1669*      CALL PLOT(3.,8.,2)
1670*      CALL PLOT(10.5,8.,2)
1671*      CALL PLOT(10.5,0.,2)
1672*      CALL PLOT(3.,0.,2)
1673*      CALL PLOT(0.79,1.3,-3)
1674*      C LABEL GRAPH
1675*      CALL SYMBOL(0.,-0.9,0.14,EVENT2,0.,72)
1676*      CALL SYMBOL(0.98,-0.9,0.14,FIG,0.,2)
1677*      CALL SYMBOL(6.16,-0.9,0.14,CM,0.,5)
1678*      C DRAW,NUMBER,LABEL X-AXIS
1679*      CALL PLOT(3.,0.,3)
1680*      CALL PLOT(9.,0.,2)
1681*      DO 55 I=1,11
1682*      X = (I-1) * 0.9
1683*      CALL PLOT(X,0.,3)
1684*      CALL PLOT(X,-0.06,2)
1685*      X = X - 0.07
1686*      FPN = (I+1) * 100.
1687*      55 CALL NUMBER(X,-0.26,0.14,FPN,0.,-1)
1688*      CALL SYMBOL(3.5,-0.48,0.14,15HWAVELENGTH (NM),0.,15)
1689*      C SET PARAMETERS FOR LINE GRAPH
1690*      XAXIS(ISIZE+1) = 200.
1691*      XAXIS(ISIZE+2) = 100. * 10./9.
1692*      C Y-AXIS ROUTINES
1693*      C ISIZE JOCKEYED TO ELIMINATE REDUNDANT SCALING
1694*      ISIZE = ISIZE/2
1695*      IF (MOD(NPLT,2) .EQ. 0) GOTO 61
1696*      CALL SCALE(YAXIS,6.,ISIZE,2)
1697*      ISIZE = ISIZE*2
1698*      YAXIS(ISIZE+2) = YAXIS(ISIZE+3)
1699*      CALL AXIS(3.,0.,30HSPECTRAL IRRADIANCE (W/CM /NM),

```

3 FIRST PLOT  
 3 NEW STACK OF PLOTS

3 ORIGIN OF AXES

3 LINEAR

```

1700*      A 30.6.,90.,YAXIS(ISIZE+1),YAXIS(ISIZE+2)
1701*      CALL SYMBOL(-0.36,3.94,0.07,1H2,90.,1)
1702*      CALL LINE(XAXIS,YAXIS,ISIZE,1,0,0)
1703*      GOTO 63
1704*      61 CALL SCALG(YAXIS,6.,ISIZE,2)          @ LOGARITHMIC
1705*      ISIZE = ISIZE+2
1706*      C DRAW,LABEL Y-AXIS
1707*      CALL PLOT(0.,0.,3)
1708*      CALL PLOT(0.,6.,2)
1709*      CALL SYMBOL(-0.43,0.9,0.14,30HSPECTRAL IRRADIANCE (W/CM /NM),
1710*      A 90.,30)
1711*      CALL SYMBOL(-0.535,4.43,0.07,1H2,90.,1)
1712*      C PLOT BOTTOM TICK AND NUMBER
1713*      CALL PLOT(0.,0.,3)
1714*      CALL PLOT(-0.12,0.,2)
1715*      CALL NUMBER(-0.4,0.,0.14,10.,0.,-1)
1716*      FPN = ALOG10(YAXIS(ISIZE+1))
1717*      CALL NUMBER(-0.135,0.175,0.07,FPN,0.,-1)
1718*      C PLOT REMAINING TICKS AND NUMBERS
1719*      II = 6. * YAXIS(ISIZE+3)          @ NUMBER OF CYCLES
1720*      YY = 0.
1721*      DO 57 I = 1,II
1722*      DO 56 J = 2,9
1723*      X = YY + ALOG10(J)/YAXIS(ISIZE+3)
1724*      CALL PLOT(0.,X,3)
1725*      56 CALL PLOT(-0.06,X,2)
1726*      YY = I/YAXIS(ISIZE+3)          @ INCH-ORDINATE OF END OF ITH CYCLE
1727*      CALL PLOT(0.,YY,3)
1728*      CALL PLOT(-0.12,YY,2)
1729*      CALL NUMBER(-0.4,YY,0.14,10.,0.,-1)
1730*      FPN = FPN + 1.
1731*      57 CALL NUMBER(-0.135,YY,0.105,0.07,FPN,0.,-1)
1732*      YAXIS(ISIZE+2) = YAXIS(ISIZE+3)
1733*      CALL LGLIN(XAXIS,YAXIS,ISIZE,1,0.,0,1)
1734*      GOTO 4
1735*      C END PLOT ROUTINE
1736*      999 CALL PLOT(12.,-36.,-3)
1737*      CALL PLOT(0.,0.5,-3)
1738*      CALL PLOT(0.,35.,2)
1739*      CALL PLOT(2.,-36.,999)
1740*      RETURN
1741*      END

```

END OF COMPILATION: NO DIAGNOSTICS.



$\lambda$	$S_{\lambda}$	$U_{\lambda}$	$V_{\lambda}$	$V'_{\lambda}$	$T_{\lambda}$	$T \cdot A_{p_{\lambda}}$	$1/C_{\lambda}$	$A_{\lambda}$
200.	.30-01	.00	.00	.00	.00	.00	.00	.10+01
201.	.33-01	.00	.00	.00	.00	.00	.00	.10+01
202.	.40-01	.00	.00	.00	.00	.00	.00	.10+01
203.	.44-01	.00	.00	.00	.00	.00	.00	.10+01
204.	.50-01	.00	.00	.00	.00	.00	.00	.10+01
205.	.53-01	.00	.00	.00	.00	.00	.00	.10+01
206.	.59-01	.00	.00	.00	.00	.00	.00	.10+01
207.	.63-01	.00	.00	.00	.00	.00	.00	.10+01
208.	.68-01	.00	.00	.00	.00	.00	.00	.10+01
209.	.71-01	.00	.00	.00	.00	.00	.00	.10+01
210.	.75-01	.00	.00	.00	.00	.00	.00	.10+01
211.	.81-01	.00	.00	.00	.00	.00	.00	.10+01
212.	.86-01	.00	.00	.00	.00	.00	.00	.10+01
213.	.90-01	.00	.00	.00	.00	.00	.00	.10+01
214.	.97-01	.00	.00	.00	.00	.00	.00	.10+01
215.	.97-01	.00	.00	.00	.00	.00	.00	.10+01
216.	.10+00	.00	.00	.00	.00	.00	.00	.10+01
217.	.11+00	.00	.00	.00	.00	.00	.00	.10+01
218.	.11+00	.00	.00	.00	.00	.00	.00	.10+01
219.	.11+00	.00	.00	.00	.00	.00	.00	.10+01
220.	.12+00	.00	.00	.00	.00	.00	.00	.10+01
221.	.12+00	.00	.00	.00	.00	.00	.00	.10+01
222.	.13+00	.00	.00	.00	.00	.00	.00	.10+01
223.	.14+00	.00	.00	.00	.00	.00	.00	.10+01
224.	.14+00	.00	.00	.00	.00	.00	.00	.10+01
225.	.15+00	.00	.00	.00	.00	.00	.00	.10+01
226.	.15+00	.00	.00	.00	.00	.00	.00	.10+01
227.	.16+00	.00	.00	.00	.00	.00	.00	.10+01
228.	.17+00	.00	.00	.00	.00	.00	.00	.10+01
229.	.17+00	.00	.00	.00	.00	.00	.00	.10+01
230.	.18+00	.00	.00	.00	.00	.00	.00	.10+01
231.	.19+00	.00	.00	.00	.00	.00	.00	.10+01
232.	.20+00	.00	.00	.00	.00	.00	.00	.10+01
233.	.21+00	.00	.00	.00	.00	.00	.00	.10+01
234.	.21+00	.00	.00	.00	.00	.00	.00	.10+01
235.	.22+00	.00	.00	.00	.00	.00	.00	.10+01
236.	.23+00	.00	.00	.00	.00	.00	.00	.10+01
237.	.24+00	.00	.00	.00	.00	.00	.00	.10+01
238.	.25+00	.00	.00	.00	.00	.00	.00	.10+01
239.	.26+00	.00	.00	.00	.00	.00	.00	.10+01
240.	.27+00	.56+00	.00	.00	.00	.00	.00	.10+01
241.	.29+00	.56+00	.00	.00	.00	.00	.00	.10+01
242.	.30+00	.56+00	.00	.00	.00	.00	.00	.10+01
243.	.32+00	.57+00	.00	.00	.00	.00	.00	.10+01
244.	.33+00	.57+00	.00	.00	.00	.00	.00	.10+01
245.	.35+00	.58+00	.00	.00	.00	.00	.00	.10+01
246.	.36+00	.58+00	.00	.00	.00	.00	.00	.10+01
247.	.38+00	.58+00	.00	.00	.00	.00	.00	.10+01
248.	.39+00	.58+00	.00	.00	.00	.00	.00	.10+01
249.	.41+00	.58+00	.00	.00	.00	.00	.00	.10+01
250.	.43+00	.57+00	.00	.00	.00	.00	.00	.10+01
251.	.44+00	.56+00	.00	.00	.00	.00	.00	.10+01
252.	.45+00	.56+00	.00	.00	.00	.00	.00	.10+01
253.	.47+00	.55+00	.00	.00	.00	.00	.00	.10+01
254.	.50+00	.54+00	.00	.00	.00	.00	.00	.10+01
255.	.52+00	.53+00	.00	.00	.00	.00	.00	.10+01
256.	.55+00	.52+00	.00	.00	.00	.00	.00	.10+01
257.	.58+00	.50+00	.00	.00	.00	.00	.00	.10+01
258.	.60+00	.48+00	.00	.00	.00	.00	.00	.10+01
259.	.63+00	.45+00	.00	.00	.00	.00	.00	.10+01
260.	.65+00	.42+00	.00	.00	.00	.00	.00	.10+01
261.	.68+00	.40+00	.00	.00	.00	.00	.00	.10+01
262.	.71+00	.36+00	.00	.00	.00	.00	.00	.10+01
263.	.75+00	.32+00	.00	.00	.00	.00	.00	.10+01
264.	.79+00	.29+00	.00	.00	.00	.00	.00	.10+01
265.	.81+00	.26+00	.00	.00	.00	.00	.00	.10+01
266.	.86+00	.23+00	.00	.00	.00	.00	.00	.10+01
267.	.88+00	.21+00	.00	.00	.00	.00	.00	.10+01
268.	.94+00	.18+00	.00	.00	.00	.00	.00	.10+01
269.	.97+00	.16+00	.00	.00	.00	.00	.00	.10+01
270.	.10+01	.14+00	.00	.00	.00	.00	.00	.10+01
271.	.10+01	.13+00	.00	.00	.00	.00	.00	.10+01
272.	.10+01	.11+00	.00	.00	.00	.00	.00	.10+01
273.	.97+00	.10+00	.00	.00	.00	.00	.00	.10+01
274.	.97+00	.90-01	.00	.00	.00	.00	.00	.10+01
275.	.95+00	.74-01	.00	.00	.00	.00	.00	.10+01
276.	.94+00	.68-01	.00	.00	.00	.00	.00	.10+01
277.	.92+00	.64-01	.00	.00	.00	.00	.00	.10+01
278.	.91+00	.62-01	.00	.00	.00	.00	.00	.10+01
279.	.91+00	.61-01	.00	.00	.00	.00	.00	.10+01
280.	.90+00	.60-01	.00	.00	.00	.00	.00	.10+01
281.	.88+00	.61-01	.00	.00	.00	.00	.00	.10+01
282.	.86+00	.62-01	.00	.00	.00	.00	.00	.10+01
283.	.84+00	.66-01	.00	.00	.00	.00	.00	.10+01
284.	.82+00	.76-01	.00	.00	.00	.00	.00	.10+01
285.	.81+00	.90-01	.00	.00	.00	.00	.00	.10+01
286.	.78+00	.11+00	.00	.00	.00	.00	.00	.10+01
287.	.75+00	.13+00	.00	.00	.00	.00	.00	.10+01
288.	.71+00	.17+00	.00	.00	.00	.00	.00	.10+01
289.	.70+00	.22+00	.00	.00	.00	.00	.00	.10+01
290.	.65+00	.31+00	.00	.00	.00	.00	.00	.10+01
291.	.63+00	.46+00	.00	.00	.00	.00	.00	.10+01
292.	.59+00	.64+00	.00	.00	.00	.00	.00	.10+01
293.	.57+00	.80+00	.00	.00	.00	.00	.00	.10+01
294.	.54+00	.92+00	.00	.00	.00	.00	.00	.10+01
295.	.50+00	.98+00	.00	.00	.00	.00	.00	.10+01
296.	.47+00	.99+00	.00	.00	.00	.00	.00	.10+01
297.	.43+00	.10+01	.00	.00	.00	.00	.00	.10+01
298.	.38+00	.98+00	.00	.00	.00	.00	.00	.10+01
299.	.33+00	.90+00	.00	.00	.00	.00	.00	.10+01








$\lambda$	$S_{\lambda}$	$U_{\lambda}$	$V_{\lambda}$	$V'_{\lambda}$	$T_{\lambda}$	$T \cdot A_{ps_{\lambda}}$	$1/C_{\lambda}$	$A_{\lambda}$	$B_{\lambda}$
1210.	.00	.00	.00	.00	.80-01	.15-01	.20+00	.00	.10-02
1215.	.00	.00	.00	.00	.73-01	.15-01	.20+00	.00	.17-02
1220.	.00	.00	.00	.00	.65-01	.15-01	.20+00	.00	.17-02
1225.	.00	.00	.00	.00	.60-01	.15-01	.20+00	.00	.17-02
1230.	.00	.00	.00	.00	.55-01	.15-01	.20+00	.00	.10-02
1235.	.00	.00	.00	.00	.53-01	.15-01	.20+00	.00	.10-02
1240.	.00	.00	.00	.00	.52-01	.15-01	.20+00	.00	.17-02
1245.	.00	.00	.00	.00	.56-01	.15-01	.20+00	.00	.10-02
1250.	.00	.00	.00	.00	.60-01	.15-01	.20+00	.00	.17-02
1255.	.00	.00	.00	.00	.63-01	.16-01	.20+00	.00	.17-02
1260.	.00	.00	.00	.00	.65-01	.17-01	.20+00	.00	.10-02
1265.	.00	.00	.00	.00	.68-01	.17-01	.20+00	.00	.10-02
1270.	.00	.00	.00	.00	.72-01	.18-01	.20+00	.00	.10-02
1275.	.00	.00	.00	.00	.77-01	.18-01	.20+00	.00	.10-02
1280.	.00	.00	.00	.00	.82-01	.18-01	.20+00	.00	.17-02
1285.	.00	.00	.00	.00	.86-01	.18-01	.20+00	.00	.17-02
1290.	.00	.00	.00	.00	.90-01	.19-01	.20+00	.00	.17-02
1295.	.00	.00	.00	.00	.95-01	.20-01	.20+00	.00	.17-02
1300.	.00	.00	.00	.00	.10+00	.20-01	.20+00	.00	.10-02
1305.	.00	.00	.00	.00	.98-01	.18-01	.20+00	.00	.17-02
1310.	.00	.00	.00	.00	.95-01	.16-01	.20+00	.00	.17-02
1315.	.00	.00	.00	.00	.90-01	.12-01	.20+00	.00	.17-02
1320.	.00	.00	.00	.00	.85-01	.10-01	.20+00	.00	.10-02
1325.	.00	.00	.00	.00	.70-01	.85-02	.20+00	.00	.17-02
1330.	.00	.00	.00	.00	.65-01	.80-02	.20+00	.00	.10-02
1335.	.00	.00	.00	.00	.59-01	.50-02	.20+00	.00	.10-02
1340.	.00	.00	.00	.00	.52-01	.40-02	.20+00	.00	.17-02
1345.	.00	.00	.00	.00	.46-01	.25-02	.20+00	.00	.10-02
1350.	.00	.00	.00	.00	.40-01	.20-02	.20+00	.00	.17-02
1355.	.00	.00	.00	.00	.33-01	.12-02	.20+00	.00	.17-02
1360.	.00	.00	.00	.00	.25-01	.10-02	.20+00	.00	.17-02
1365.	.00	.00	.00	.00	.20-01	.70-03	.20+00	.00	.17-02
1370.	.00	.00	.00	.00	.15-01	.00	.20+00	.00	.17-02
1375.	.00	.00	.00	.00	.13-01	.00	.20+00	.00	.17-02
1380.	.00	.00	.00	.00	.10-01	.00	.20+00	.00	.17-02
1385.	.00	.00	.00	.00	.80-02	.00	.20+00	.00	.17-02
1390.	.00	.00	.00	.00	.50-02	.00	.20+00	.00	.17-02
1395.	.00	.00	.00	.00	.25-02	.00	.20+00	.00	.17-02
1400.	.00	.00	.00	.00	.10-02	.00	.20+00	.00	.10-02


$\lambda$	$P_{445}$	$P_{535}$	$P_{575}$
410.	.67+00		
420.	.81+00		
430.	.92+00	.22+00	
440.	.99+00	.28+00	
450.	.98+00	.33+00	.80-01
460.	.98+00	.42+00	.13+00
470.	.73+00	.51+00	.20+00
480.	.53+00	.61+00	.26+00
490.	.33+00	.72+00	.35+00
500.	.18+00	.82+00	.45+00
510.	.00-01	.90+00	.54+00
520.	.50-01	.96+00	.62+00
530.	.30-01	.99+00	.72+00
540.	.10-01	.99+00	.80+00
550.		.98+00	.86+00
560.		.86+00	.93+00
570.		.74+00	.99+00
580.		.61+00	.99+00
590.		.47+00	.94+00
600.		.36+00	.81+00
610.		.24+00	.70+00
620.		.16+00	.55+00
630.		.10+00	.42+00
640.		.70-02	.29+00
650.		.40-01	.17+00
660.		.30-01	.80-01
670.		.20-01	.20-01
680.		.10-01	.50-02






S-LAMBDA

B-36




U-LAMBDA

B-37



V-LAMBDA


B-38




V\*-LAMBDA

B-39







T-LAMBDA B-40



T-A-LAMBDA B-41




C-A-LAMBDA B-42




A-LAMBDA 8-43






BLUE HAZARD

B-44




X-BAR DATA

B-45



Y-BAR DATA


B-46




Z-BAR DATA

B-47






P445 DATA 8-48



P535 DATA

B-49



P575 DATA B-50

## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

### APPENDIX C

#### OPERATING INSTRUCTIONS

The following data will not change from run to run: S-, U-, A-, T-, T-A-, C-A-, V-, V\*-, B-LAMBDA, X-BAR LAMBDA, Y-BAR LAMBDA, Z-BAR LAMBDA, P-445, P-535, and P-575. Other data vary with the run; the data decks must terminate with the proper END card and should be labeled on top. The run request must be checked to be certain that the data required by the calculation control card are supplied.

There must be two source description cards, even if one or both are blank. The calcomp plot requires wide paper.

The same calculation and calibration data may be used for several sources. However, changing any calculation or calibration data during a run can be accomplished by using 'NEXT' as the event number on the event card. Control then branches to the beginning of the program, and expects two project description cards, etc, as if this were a different run request.



## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

### MESSAGES/HALTS

#### Messages

'CALIBRATION DATA NOT ENDED CORRECTLY'

'BIODECK DOES NOT HAVE AN END CARD'

'FILTER DATA WERE NOT ENDED CORRECTLY'

'GENERAL FUNCTION DOES NOT END CORRECTLY'

'SPECTRAL READINGS WERE NOT ENDED CORRECTLY'

Causes- No END card for data section. Or more than 340 cards in section.

Effect on program- Print error message and abort run.

Action- Insert END card at end of appropriate section; if END card is present, check spelling. Or remove extra cards. And rerun.

#### Message

'WAVE LENGTH XXXX OF SPECTRAL IRRADIANCE DOES NOT MATCH WAVE LENGTH OF READING FOR CALIBRATION FACTOR'

Cause- As in message.

Effect on program- Print error message and abort run.

Action- Correct errors on data cards and rerun.

#### Message

'DIVISION BY ZERO IN CALIBRATION FACTOR SECTION AT WAVE LENGTH XXXX'

Cause- Datum in second set of raw calibration data is zero.

Effect on program- Print error message and abort run.

Action- Correct error on data card and rerun.

#### Message

'CALIBRATION FACTOR ERROR-NUMBER RAW DATA NOT MATCHED'

Cause- Second set of raw calibration data has different number of items than first set.

Effect on program- Print error message and abort.

Action- Insert missing data and rerun.

#### Message

'ATTEMPT TO DIVIDE A CALIBRATION FACTOR OF ZERO INTO ADJUSTED INSTRUMENT READING AT WAVELENGTH XXXX'

Cause- First set of raw calibration data contains a zero.

Effect on program- Print error message and abort.

Action- Change zero to valid value and rerun.

#### Message

'ALL PROCESSING COMPLETED'

Cause- Normal completion of program.

Effect on program- Normal completion.

Action- None required.

## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

### INSTRUCTIONS FOR FILLING OUT FORMS

The data for the LMD Spectral Weighting Program must be entered on a number of coding forms in order to input the information to the computer. Explicit instructions for filling out each form are provided below:

A. Cover Sheet. These data are used to identify the information for future reference and determine the kinds of input data to the Data Processing personnel. Item-by-item instructions are given below.

1. Project Number. Fill in local project number which will identify the spectral source or filter.

2. Source Description. Briefly give source description and/or project name (20 words or less). Adequately describe source for future reference.

3. Calibration Deck Used. List number of calibration deck. This deck may be on file with the computer center or the calibration factors may be submitted with the rest of the forms.

4. Calculation Control Card. Enter code number in each box which describes the kinds of data which will be run. Two filters with known spectral characteristics may be submitted with the source data if desired. Normally, instrument readings are submitted which permit the computer to calculate the spectral irradiance,  $E_\lambda$ , by dividing the reading by the calibration factor; however, spectral irradiance values may be the direct input without a calibration factor if desired. One specific biologic function weighted against the source spectrum may be listed spectrally if desired. One of the following codes should be inserted in columns 4 and 5 of this card to specify this function.

- 00 -- None
- 01 --  $S_\lambda$  -- Ultraviolet Irradiance According to ACGIH Action Spectra
- 02 --  $U_\lambda$  -- Ultraviolet Irradiance According to CIE Action Spectra
- 03 --  $A_\lambda$  -- Ultraviolet Irradiance According to ANSI Action Spectra
- 04 -- T -- Transmission of the Ocular Media  $\times E_\lambda$
- 05 -- T·A -- Transmission of the Ocular Media  $\times$  Absorption of Retina  $\times E_\lambda$
- 06 --  $1/C_A$  -- Reciprocal of ANSI MPE Weighting Factor
- 07 --  $V_\lambda$  -- Photopic Spectral Luminous Efficiency  $\times E_\lambda$
- 08 --  $V_\lambda'$  -- Scotopic Spectral Luminous Efficiency  $\times E_\lambda$
- 09 --  $B_\lambda$  -- Blue Light Hazard Function  $\times E_\lambda$
- 10 --  $\bar{X}_\lambda$  -- Spectral Tristimulus value (red)  $\times E_\lambda$
- 11 --  $\bar{Y}_\lambda$  -- Spectral Tristimulus value (green)  $\times E_\lambda$
- 12 --  $\bar{Z}_\lambda$  -- Spectral Tristimulus value (blue)  $\times E_\lambda$
- 13 -- P<sub>445</sub> -- Dartnall Nomogram Absorption Coefficient for Blue  $\times E_\lambda$
- 14 -- P<sub>535</sub> -- Dartnall Nomogram Absorption Coefficient for Green  $\times E_\lambda$
- 15 -- P<sub>575</sub> -- Dartnall Nomogram Absorption Coefficient for Red  $\times E_\lambda$

## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

5. **Number of Data Decks Submitted.** Enter the number of individual source spectrums which are being submitted at this time under this cover sheet.

6. **Check List.** Be sure all listed information is submitted either on or with the cover sheet.

B. **Source Data Sheet.** This form is the first form used for recording spectral data by wavelength -- Instrument reading from a particular instrument. All three items on this form must be filled in.

1. **Source Name.** The source name is used to distinguish between several source spectrums entered under the same cover sheet. This name should be kept under 8 characters if possible.

2. **Source Solid Angle.** The Solid Angle of the source must be entered in exponential notation (example,  $1.00E-05$ ). If the solid angle is not known, an approximation must be used.

3. **Data Values.** Values are entered in integer form for wavelength and exponential form for instrument reading. The wavelength values must be placed in the rightmost columns ( 235, not 235 ). Spectral peaks may be identified to the right of the instrument readings by inserting the word "PEAK" in the indicated columns. These values are then treated separately by the computer program.

C. **Calibration-Filter Sheet.** This form may be used for calibration or for filter information. Information should be placed in the first two columns by wavelength and value. The type of coded information should be identified at the top of the form.

D. **Data Continuation Sheet.** This form may be used for continuation of either source data or calibration values.

E. **End Card.** At the end of either the source data deck or at the end of the calibration deck, the statement "END of Spectral Data" or "END of Calibration Deck" must be inserted.



## Technical Guide - Hazard Analysis of Broad-Band Optical Sources

### EXPANDED PROGRAM USE

Some additional features are built into the program. However their use is not recommended for general use. Key personnel may be required to assemble the run stream and thereby increase the processing time. Some of these features are listed below.

A. Distance Factors. These two factors may be used to adjust calibration values for variations in the distance from a standard lamp that a piece of equipment was placed for calibration. For instance, if the required measurement distance was 50 cm and the calibration was made at 100 cm, a distance factor of 4.0 could be inserted into the program. However, the READ statement was deleted from the program which read in these values. These two factors are designated DFU and DFV and are applied to the UV portion of the spectrum and the visible and near-IR portion respectively.

B. Uncomputed Calibration Deck. The calibration values may be submitted in two decks rather than one. The program will then divide the instrument readings (first deck) by the spectrum of the standard lamp (second deck). If data are submitted in this form, a zero is placed in column 3 of the Calculation Control Card.

C. Uncomputed Filter Data. Filter data may be submitted in two columns rather than one following the wavelength values. The second column is then divided by the first. Enter a "2" in column 2 of the Calculation Control Card to run the program this way.

D. General Function. Part of the source data may be corrected if found faulty after the cards have been punched. The deck may be corrected throughout certain wavelength regions by the use of this function. The starting wavelength, the ending wavelength, and the correction factor are coded on the special form provided. As many correction cards as needed may be used. An "END" card must be placed at the end of this function.

E. Expanded Run Stream. The order of the various inputs is listed below.

1. Source Description (two cards)
2. Calculation Control Card
3. Distance Factors (program change required)
4. Calibration Deck
5. Standard Lamp Data (if required)
6. BIO Deck
7. Filter Transmissions
8. General Function
9. Source Name (Event)
10. Source Solid Angle
11. Source Data Readings



# Technical Guide - Hazard Analysis of Broad-Band Optical Sources

## LASER MICROWAVE DIVISION SPECTRAL WEIGHTING PROGRAM

### COVER SHEET

A. PROJECT NUMBER: 42-\_\_\_\_\_.

B. SOURCE DESCRIPTION: \_\_\_\_\_

(free format,  
158 spaces)

C. CALIBRATION DECK USED: DECK NUMBER \_\_\_\_\_  
☐ ON FILE ☐ INCLUDED WITH DATA DECK

D. CALCULATION CONTROL CARD:

1	2	3	4	5

BOX NUMBER:

1. Number of Filters to be Processed -- Enter Number (maximum is two)

2. Leave Blank

3. Form of Calibration Deck:

a. Regular -- Enter "1"

b. None Required -- Enter "2"

4-5. Specific Biologic Function to be Listed Spectrally -- Enter code

a. None -- 00

e. T -- 04

i.  $V_{\lambda}'$  -- 08

m.  $Z_{\lambda}$  -- 12

b.  $S_{\lambda}$  -- 01

f. T'A -- 05

j.  $B_{\lambda}$  -- 09

n. P445 -- 13

c.  $U_{\lambda}$  -- 02

g.  $1/C_A$  -- 06

k.  $X_{\lambda}$  -- 10

o. P535 -- 14

d.  $A_{\lambda}$  -- 03

h.  $V_{\lambda}$  -- 07

l.  $Y_{\lambda}$  -- 11

p. P575 -- 15

E. NUMBER OF DATA DECKS SUBMITTED: \_\_\_\_\_.

F. CHECK LIST: ☐ Source Description

☐ Instrument Readings

☐ Calculation Control Card

☐ Solid Angle

☐ Calibration Deck

Identification					
75	76	77	78	79	80

[illegible]

—

Journal of Management Education 32(1)

Journal of Management Education 32(1)



LMSVP Form 2, 10 Dec 76

# Technical Guide - Hazard Analysis of Broad-Band Optical Sources

## APPENDIX D

ISERIL CIE: RADIOMETRIC AND PHOTOMETRIC TERMS AND UNITS<sup>1, 2</sup>

RADIOMETRIC				PHOTOMETRIC			
Term	Symbol	Defining Equation	SI Unit and Abbreviation	Term	Symbol	Defining Equation	SI Units and Abbreviation
Radiant Energy	$Q_e$		Joule (J)	Quantity of Light	$Q_v$	$Q_v = \int \phi_v dt$	lumen-second (lm·s) (talbot)
Radiant Energy Density	$W_e$	$W_e = \frac{dQ_e}{dV}$	Joule per cubic meter (J·m <sup>-3</sup> )	Luminous Energy Density	$W_v$	$W_v = \frac{dQ_v}{dV}$	talbot per square meter (lm·s·m <sup>-2</sup> )
Radiant Power (Radiant Flux)	$\phi_e, P$	$\phi_e = \frac{dQ_e}{dt}$	Watt (W)	Luminous Flux	$\phi_v$	$\phi_v = 680 \int \frac{d\phi_e}{d\lambda} V(\lambda) d\lambda$	lumen (lm)
Radiant Exitance	$M_e$	$M_e = \frac{d\phi_e}{dA} = \int L_e \cos \theta d\Omega$	Watt per square meter (W·m <sup>-2</sup> )	Luminous Exitance	$M_v$	$M_v = \frac{d\phi_v}{dA} = \int L_v \cos \theta d\Omega$	lumen per square meter lm·m <sup>-2</sup>
Irradiance or Radiant Flux Density (Dose Rate in Photobiology)	$E_e$	$E_e = \frac{d\phi_e}{dA}$	Watt per square meter (W·m <sup>-2</sup> )	Illuminance (luminous flux density)	$E_v$	$E_v = \frac{d\phi_v}{dA}$	lumen per square meter (lm·m <sup>-2</sup> ) lux (lx)
Radiant Intensity	$I_e$	$I_e = \frac{d\phi_e}{d\Omega}$	Watt per steradian (W·sr <sup>-1</sup> )	Luminous Intensity (candlepower)	$I_v$	$I_v = \frac{d\phi_v}{d\Omega}$	lumen per steradian (lm·sr) or candela (cd)
Radiance	$L_e$	$L_e = \frac{d^2\phi_e}{d\Omega \cdot dA \cdot \cos \theta}$	Watt per steradian and per square meter (W·sr <sup>-1</sup> ·m <sup>-2</sup> )	Luminance	$L_v$	$L_v = \frac{d^2\phi_v}{d\Omega \cdot dA \cdot \cos \theta}$	candela per square meter (cd·m <sup>-2</sup> )
Radiant Exposure (dose, in Photobiology)	$H_e$	$H_e = \frac{dQ_e}{dA}$	Joule per square meter (J·m <sup>-2</sup> )	Light Exposure	$H_v$	$H_v = \frac{dQ_v}{dA} = \int E_v dt$	lux-second (lx·s)
				Luminous Efficacy (of radiation)	$K$	$K = \frac{\phi_v}{\phi_e}$	lumen per watt (lm·W <sup>-1</sup> )
				Luminous Efficiency (of a broad band radiation)	$V(\cdot)$	$V(\cdot) = \frac{K}{K_m} = \frac{K}{680}$	unitless
Radiant Efficiency <sup>3</sup> (of a source)	$\eta_e$	$\eta_e = \frac{P}{P_i}$	unitless	Luminous Efficacy <sup>3</sup> (of a source)	$\eta_v$	$\eta_v = \frac{\phi_v}{P_i}$	lumen per watt (lm·W <sup>-1</sup> )
Optical Density <sup>4</sup>	$D_e$	$D_e = -\log_{10} T_e$	unitless	Optical Density <sup>4</sup>	$D_v$	$D_v = -\log_{10} T_v$	unitless
				Retinal Illuminance in Trolands	$E_t$	$E_t = \frac{L_v}{S_p}$	troland (td)= luminance in cd·m <sup>-2</sup> times pupil area in mm <sup>2</sup>

1. The units may be altered to refer to narrow spectral bands in which case the term is preceded by the word *spectral*, and the unit is then per wavelength interval and the symbol has a subscript  $\lambda$ . For example spectral irradiance  $I_{\lambda}$  has units of W·m<sup>-2</sup>·m<sup>-1</sup> or more often, W·cm<sup>-2</sup>·nm<sup>-1</sup>.

2. While the meter is the preferred unit of length, the centimeter is still the most commonly used unit of length for many of the above terms and the nm or  $\mu$ m are most commonly used to express wavelength.

3.  $P_i$  is electrical input power in watts. 4.  $\tau$  is the transmission

5. At the source  $I = \frac{dI}{d\Omega \cos \theta}$  and at a receptor  $I = \frac{dI}{d\Omega}$

IED  
78